Lynx[®] SmartHub for LSM, LAC, and GAC Installation and User Guide (DEC, LAC, and DAC Series)







Scan here for foreign language translations.



Scanner ici pour une traduction en langue étrangère.



Busque aquí la traducción de idiomas extranjeros.

Browser? Navigateur? Navegador? Go to https://www.toro.com/en/golf/irrigation-field-controllers/lac-decoder

Table of Contents			
Toro's Commitment to Excellence	3	Lynx Communication Cable	24
Introduction Cabinet Installation	3 4	Communicating Between Lynx and SmartHub Layout 1 - Local	25 25
Wallmount Power Source	4 5	Layout 2 - Wired Lynx Layout 3 - Wireless To Test Radio Communication	26 26
Pedestal Installation Foundation Construction Earth Ground	6 6 7	Communication Test Between Lynx and SmartHub Changing the Frequency of the Radio	27 28
Power Source Lynx SmartHub Module (LSM) Installation New System / New Communication Cable	9 10 10	SmartHub Operation Modes of Operation General Editing	30 30 30
LAC Decoder Installation Comm Cable Type & Configuration Comm Cable Length Measuring Cable Resistance	12 12 13	Initial Setup Editing Large Values Timing Mechanism Components Power-Up Diagnostics	30 30 31 32
Max Number of Decoders Burial Depth Comm Cable to Power Spacing Decoder to Sprinkler Wires	13 13 13 13 13	Flome Button Start Button Pause Button Stop Button Unit Settings	32 33 33 33 34
Valve Compatibility Decoder Installation Steps LAC Decoder Surge Protection and Grounding	13 15 15	% (Percent) Adjust Station Settings Scheduled Watering Manual Watering	36 36 38 39
LAC Motherboard Connections Switch Position Synchronization	17 17 17	Diagnostics LAC Decoder Diagnostics Motherboard Diagnostic Display	41 44
Master Valve / Pump Relay	17	and Alarms	45 47
GAC Decoder Installation New System / New Communication Cable Upgrade of Existing System	18 18 20	Radio Fuse and Circuit Breaker Lynx SmartHub	47 47 47 47
Grounding GAC and DC Communication Cable	21	Warranty and Agency Statement	47
GAC and LSM Motherboard Connections Synchronization Status Sensor Rain Sensor Flow Sensor Master Valve / Pump Relay	23 23 23 23 23 23 23		

Toro's Commitment to Excellence

Toro is committed to developing and producing the highest quality, best performing, most dependable products on the market. Because your satisfaction is our first priority, we have provided the Toro Helpline to assist you with any questions or problems that may arise. If for some reason you are not satisfied with your purchase or have questions, please contact us toll free at 1-877-345-8676.

Introduction

Congratulations on purchasing Toro's Lynx SmartHub for LSM (Lynx Smart Module), LAC, or GAC.

The SmartHub combines modular flexibility, ease of use and increased programmability in a single controller. The user interface is easy to use and includes a backlight for improved visibility in low-light conditions, yet it is completely viewable in direct sunlight. The faceplate's combination of menu buttons, navigation arrows and input dial allows for easy and quick menu navigation.

The Lynx SmartHub comes in twelve versions:

- DEC-RS-1000-DR (digital radio)
 - LAC-RS-1000-M LAC-RSP-1000-M •
- DEC-RSP-1000-M (modem only) • DEC-RSB-1000-M
- DEC-RST-1000-M
- LAC-RSB-1000-M
- LAC-RST-1000-M •
- DAC-RS-1000-DR
- DAC-RS-1000-M
- DAC-RSP-1000-DR
- DAC-RSP-1000-M

The Lynx SmartHub satellite controller pedestal is designed for installation on a substantial concrete foundation with imbedded conduit of various diameters to enable power, field, ground and communication wiring to be routed into the pedestal for connection. A mounting bolt positioner and basic mounting hardware components are included with each controller. Additional materials required to complete the installation must be obtained separately. A material list can be compiled by reading through the instructions completely prior to starting the installation.

CAUTION: For your protection and the safety of the product user, comply with all Caution and Warning statements within this document. All installation practices must comply with all applicable national and/or local electrical and construction codes.



Note for model numbers: DEC is also referred to as LSM. DAC is also referred to as GAC.

Cabinet Installation

Wallmount

Selecting the proper installation site for the Lynx SmartHub is essential to safe and reliable operation. The SmartHub features a weather resistant cabinet designed for indoor or outdoor installation.

Install the Lynx SmartHub:

- on a vertical wall or other sturdy structure
- so that the display is at or below eye level
- near a grounded power source
- so that it is in shade during the hottest hours of the day
- with as much protection from direct sunlight, rain, wind and snow as possible

IMPORTANT! Do not mount the controller where it is exposed to direct spray from the irrigation system.

IMPORTANT! Use power tool and equipment suitable for the application. Consult and follow the safety guidelines outlined by the power tool or equipment manufacturer.

Steps:

- 1. Drill two pilot holes 6" (15.25cm) apart for the top keyholes of the controller cabinet.
- Install the top screws leaving approximately 1/4" (5–6mm) of exposed screw to accommodate the cabinet.



User a #10 one-inch screw or equivalent. If
 mounting the cabinet on dry wall or masonry, install the appropriate type of screw anchors or fasteners to ensure secure installation.

- 3. Hang the cabinet using the top keyhole slots. See **Figure 1**.
- 4. Open the cabinet door and install the two bottom screws to secure the cabinet.



Power Source



IMPORTANT SAFETY INSTRUCTIONS

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE AND LOCAL JURISDICTION BY A PERSON FAMILIAR WITH THE CONSTRUCTION, INSTALLATION, AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

THE USE OF OR INSTALLATION OF JUNCTION BOXES, CONDUIT BODIES, AND FITTINGS SHALL BE FOR THE INSTALLATION AND INTENDED USE AND IN ACCORDANCE WITH APPLICABLE ELECTRICAL CODE. CONSULT WITH A QUALIFIED ELECTRICIAN AND LOCAL ELECTRICAL CODES BEFORE INSTALLING ANY ELECTRICAL PRODUCT.

DISCONNECT ALL POWER BEFORE SERVICING. ENSURE MAIN AC BREAKER IS OFF. FAILURE TO COMPLY MAY RESULT IN SERIOUS INJURY DUE TO ELECTRICAL SHOCK HAZARD.

Steps:

1. Turn off the power at the power source location and place the controller's power switch to OFF. Connect and route the appropriate size 3-conductor cable (14 AWG [2.5mm²] maximum) from the power source to the controller cabinet.

The provided power cable access hole can accommodate a 1" (25mm) conduit fitting. If conduit is required, install a section of flexible 1" (25mm) electrical conduit from the power source conduit box to the cabinet's access hole.

- 2. Open the cabinet door and remove the two retaining screws from the power supply cover.
- **3.** Strip the power cables and secure them to the terminal block (**Figure 3**). Reference **Table 1** for the appropriate type of power connection.
- 4. Reinstall the power supply cover.
- **5.** Apply power to the controller.

Table 1			
AC Service Type	Line	Neutral	Equipment Ground
100 – 120 VAC (Domestic)	Hot (Black)	Neutral (White)	Green
200 – 240 VAC (International)	Hot (Brown)	Neutral (Blue)	Green / Yellow



Pedestal Installation

Foundation Construction

1. Prepare a hole for the foundation and wiring conduit using the minimum recommended dimensions shown in **Figure 4**.

* Refer to local electrical codes for required depth of buried wiring .

- 2. Trench to the foundation site as required for each wiring run.
- Position straight and sweep elbow conduit sections in foundation hole as shown. Tape the conduit ends to seal out dirt. Backfill soil to form a 6" (15.2cm) foundation depth. Conduit should not extend more than 2" above the finished top surface of the foundation.
- 4. Prepare the sides of the foundation hole with wood forms.
- Prepare the mounting bolt positioner with the 5/16 x 4-1/2" bolts and nuts (provided) as shown in Figure 3. The threads should extend 2" (51mm) from the top surface of the bolt positioner.
- 6. Pour concrete into the formed foundation hole. Press the mounting bolt positioner into the concrete until it is flush and level with the foundation surface and aligned with the conduit.
- 7. Finish the concrete with a level flat area for the pedestal base (13" x 13" [33cm x 33cm] for the metal pedestal or 16" x 16" [41cm x 41cm] for the plastic pedestal). To prevent pooling at the base of the pedestal, add a slight taper away from the pedestal base contact area. Allow concrete to sufficiently harden before continuing.
- 8. Remove the hex nuts from the mounting studs. Carefully position the controller onto the studs. Install a flat washer and a hex nut on each stud and tighten securely.



Earth Ground

IMPORTANT! The Lynx SmartHub surge protection components cannot properly function unless an efficient pathway to earth ground is provided. The ground path must be as direct as possible, without sharp bends and should not exceed 10 Ohm resistance (when measured with an earth ground resistance device). All electrical components throughout the irrigation system should be grounded similarly to provide the same ground potential.

The following instructions depict one of several acceptable earth grounding methods. Due to variables in soil composition and terrain, the method shown may not be suitable for your installation site. Contact your local Toro distributor for assistance and availability of the required earth ground resistance test instrument. Recommended ground testers are: AEMC Instruments, model 3710 clamp-on tester, or Biddle Megger, model 250260 (or equivalent).

IMPORTANT! Prior to excavating, digging, or trenching, consult with local utility locating service or authority having jurisdiction to prevent damage and protect utility infrastructure.

Procedure

- Drive a 5/8" by 8' (17mm x 2.5m) copper clad steel rod into well moistened soil not less than 8' (2.5m) or not more than 12' (3.7m) from the controller cabinet (see Figure 5 and 6). The top of the ground rod should be flush with or below ground level, and should be protected from damage using a valve box (A).
- 2. Measure the ground resistance per the instructions provided with the ground test instrument.
 - If reading is 10 ohms or less, proceed to step 4.
 - If reading is greater than 10 ohms, proceed to step 3.
- 3. Install a 4" by 96" (10cm x 2.5m) copper ground plate. The plate should be at least .06" thick (1.5mm) and should have a 6 AWG x 12' (10mm² x 4m) solid copper, insulated wire welded to the plate. The plate should go into a trench that is at least 30" (80cm) deep (B)). Use ground enhancement material (GEM) per the manufacturer's directions.
- 4. Using a 5/8" (17mm) clamp or exothermic-weld fastener, attach an 8 AWG (10mm²) solid copper wire near the top of the ground rod.
- Route the wire through conduit and into the controller cabinet, avoiding wire bends of less than 8" (20cm) radius and more than 90° (C). Secure the wire to the copper ground lug in the controller.
- 6. Measure the ground resistance again. A reading of 10 ohms or less is recommended.



Lynx® SmartHub Installation and User Guide



Toro-Approved Wire Splices for the Lynx Smart Module Communication Cable

CAUTION: All wire splices must be made using appropriate methods and materials to protect the connection from water contamination.

In 2-wire control systems, the communication cable is powered for extended periods providing data communication to each sprinkler via a control cable that is daisy chained from sprinkler to sprinkler with a critical splice at each sprinkler along the wire path.

The operational nature of these systems and the sheer quantity of wire connections requires that the wire splice be done in a very professional manner using the highest quality materials that provide true waterproofing in the most severe conditions that include being fully submerged.

For this reason, the Toro Company has created a specification for approved cable and wire splices, form number **373-1046**. Please refer to this specification to identify the cable and wire splices approved by the Toro Company for use in 2-wire system applications.



Throughout this manual the symbol to the left is used to represent a Toro-approved water-proof wire-splice.

For a complete list of Toro approved 2-wire communication cable and wire splices, see document *373-1046, Lynx Smart Module Wire and Splices*.

When properly installed, Toro-approved wire splices will ensure the integrity of the connection and communications even in the most adverse conditions such as full submersion.

Power Source



IMPORTANT SAFETY INSTRUCTIONS

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE AND LOCAL JURISDICTION BY A PERSON FAMILIAR WITH THE CONSTRUCTION, INSTALLATION, AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

THE USE OF OR INSTALLATION OF JUNCTION BOXES, CONDUIT BODIES, AND FITTINGS SHALL BE FOR THE INSTALLATION AND INTENDED USE AND IN ACCORDANCE WITH APPLICABLE ELECTRICAL CODE. CONSULT WITH A QUALIFIED ELECTRICIAN AND LOCAL ELECTRICAL CODES BEFORE INSTALLING ANY ELECTRICAL PRODUCT.

DISCONNECT ALL POWER BEFORE SERVICING. ENSURE MAIN AC BREAKER IS OFF. FAILURE TO COMPLY MAY RESULT IN SERIOUS INJURY DUE TO ELECTRICAL SHOCK HAZARD.

- Turn off the power at the power source location and place the controller's power switch to OFF. Connect and route the appropriate size 3-conductor cable (14 AWG [2.5mm2] maximum) from the power source to the controller pedestal. The provided power cable access hole can accommodate a 1" (25mm) conduit fitting. If conduit is required, install a section of flexible 1" (25mm) electrical conduit from the power source conduit box to the pedestal's access hole.
- 2. Strip the power cables and secure them to the terminal block. Reference **Table 1** and **Figure 7** for the appropriate type of power connection.
- 3. Reinstall the power supply cover.
- 4. Apply power to the controller.

Table 1			
AC Service Type	Line	Neutral	Equipment Ground
100 – 120 VAC (Domestic)	Hot (Black)	Neutral (White)	Green
200 – 240 VAC (International)	Hot (Brown)	Neutral (Blue)	Green / Yellow



Lynx Smart Module Installation

New System or New Communication Cable

Lynx Smart Modules are available in 1-station configurations.

The SmartHub pedestal and cabinet can handle up to 1000 modules or 1000 stations each. The SmartHub with Lynx Smart Modules (LSMs) can accommodate up to two daughterboards with two output circuits. Each daughterboard can handle up to 500 modules and stations. The modules can be connected in parallel anywhere on the two-wire communication line connected to the station terminals. Each cable path can handle up to 250 modules and stations. Each station can activate up to two solenoids.

It is recommended that the modules are installed in an approved valve box to provide easy access to the wiring. Use approved splice to waterproof all connectors.

Recommended Controller-to-Module cable: 14 AWG (2.1 mm2), solid copper, jacketed 2-conductor, direct burial. **Recommended Module-to-Solenoid cable:** 14 AWG (2.1 mm2), solid copper, 2-conductor, direct burial.

Burial Depth

Toro recommends that the Controller-to-Module and Module-to-Solenoid cables should have a minimum cover of 6" (150mm). The irrigation plan may specify additional depth to be consistent with the depth of mainline or lateral pipe work and/or soil conditioning procedures such as aeration. Installation procedures must comply with all applicable local and national electrical codes.

- Use only wire approved for direct burial if installing the wires underground without conduit.
- All field wiring splices must be accessible to facilitate troubleshooting and/or service.

Steps:

1. Route communication cable from the controller to the station module installation location.

The maximum wire length between the controller and the module is 15,000' (4500 m).

- 2. Secure the communication wires to terminal 1 of the SmartHub output board. White wire onto the 1st terminal and black wire onto the second terminal. See **Figure 8**.
- 3. Install the module in a valve box. Record the module's address number found on the side label. This address number identifies the station(s) that the module control.
- 4. Secure the communication wires to the module's black and white wires. Connect the black communication wire to the black module wire. Connect the remaining communication wire (red or white) to the white module wire. Use approved splice to properly water-proof all wire connections.
- 5. Route output wires from the module to the solenoid.

The maximum wire length between the module and the solenoid is 410' (125m) for 14 AWG (2.5mm²) wire.

- 6. Connect the solenoid wires to the module's station wires. The station wires are color coded for easy identification. Connect the solid red colored station wire to the red/white solenoid wire. Connect the similar color station wire with black stripe to the black solenoid wire. Use approved splice to properly water-proof all wire connections.
- 7. Connect an additional solenoid to the station wire as necessary.Reach station has a maximum load of two solenoids.
- 8. Repeat Steps 3–8 for additional modules.

Wire splices

For an explanation of Toro-approved wire splices indicated by the wire splice symbol please refer to the **Toro-Approved Wire Splices** inset on **page 8**.





LAC Decoder Installation

The LAC SmartHub controller supports older FD (field decoder) type decoders and newer LAC (Lynx AC) decoders. Both types of decoders can be installed in parallel along a two-wire communication cable that connects to the controller. LAC decoders provide more diagnostics and are available in 1, 2, 4, and 6-station outputs. One and two station LAC decoders are available with outputs for single or dual solenoids. The controller pedestal and cabinet have one daughter board that can handle up to 800 decoders or stations. One hub can have a maximum of 800 LAC or 500 FD type decoders installed. See the **Maximum Number of Decoders** section on the next page for mixing these types.

LAC is meant to be installed as a new system or as an upgrade to an existing system. Existing systems should be qualified with an LAC site evaluation worksheet. The evaluation process involves recording or measuring cable type, cable length, cable configuration, the number of decoders and stations, testing of furthest decoder from controller, measuring capacitance, voltage at the end of line, and leakage current.

Communication Cable Type and Configuration

The recommended controller-to-decoder cable is 2.5mm² or 14 AWG, solid copper, jacketed 2-conductor, direct burial. 14 AWG has a slight decrease in maximum cable length from the 2.5mm². Use approved splices to waterproof all connections. Exposed ends must be capped and sealed with approved splices.

The LAC controller communicates and provides power to decoders through cables that consist of two insulated wires. These two-wire cables connect to the hub at the daughter board output terminals. One cable wire goes to a terminal labeled A and the other to B.

The two-wire path can be installed in two types of configuration: Star and Loop. Star configurations are when the two-wire cables branch throughout the course from the hub and terminates on the course (**Figure 9**). The path can branch multiple times from the terminals as long as distance and resistance requirements between hub and decoders are not exceeded. Star configurations are recommended because they are easier to troubleshot.

Loop configurations are when the two-wire cable goes out and loops back to the terminals. Both ends of the cable connect at or near the terminals. They support longer cable distances but are more difficult to troubleshoot.

The LAC controller output terminals accommodate up to 4 two-wire cable connections (8 individual wires). It can handle a maximum of 4 star or 2 loops. There are four terminal screws that can accommodate two wires. More than two cables will require two wires to be secured with one terminal screw.



Communication Cable Length

The maximum two-wire cable length to the furthest decoder from the LAC SmartHub depends on the wire gauge used. For 2.5mm², it is 3,000 meters (9,800') for star configurations and 12,000 meters (39,370') for loop configurations. For loop configuration, it is the total distance from the SmartHub out and back. This is four times the cable length of the star configuration but is not recommended as they are difficult to troubleshoot.

Wire	Star	Loop
2.5mm ²	3km (9,800')	12km (39,200')
4.0mm ²	4.7km (15,400')	18.8km (61,600')
14 AWG	8,800' (2.7km)	35,200' (10.8km)
12 AWG	14,000' (4.2km)	56,000' (16.8km)

Maximum cable length to furthest decoder:

Measuring Cable Resistance

For star configurations, the resistance of the two-wire cable path between the SmartHub to the furthest decoder should be 45 Ohms or less. This can be measured by shorting the wires together at one end of the cable near the hub and measuring the resistance between the wires at the other end near the furthest decoder. Alternately, the wires at the far end can be shorted and the resistance measured at the end near the hub.

For loop configurations, both ends of the two-wire cable path are at the hub terminals. Short the wires together at one end and not the other. The resistance between the wires at the non-shorted end should be 180 Ohms or less.

Maximum Number of Stations

A station is one addressable decoder output. The maximum number of stations on one LAC SmartHub is 800 LAC or 500 FD stations. One wire path from the SmartHub that terminates on the course (star configuration) can have a maximum of 400 LAC decoders or 250 FD decoders. Multiple runs can be used. For mixed systems of both types, the maximum number is given by the following:

LAC stations per hub = 800 - (1.6 * FD stations). FD stations per hub = (800 - LAC stations)/1.6. LAC stations per wire path = 400 - (1.6 * FD stations)FD stations per wire path = (400 - LAC stations)/1.6

Example 1: with 200 FD stations, the maximum number of LAC stations per hub is 800 - (1.6 * 200) = 480. The maximum for that wire path is 400 - (1.6 * 200) = 80. More than 80 LAC stations requires another wire path.

Example 2: with 351 LAC stations, the maximum number of FD stations per hub is (800 - 351)/1.6 = 280. The maximum for that wire path is (400 - 351)/1.6 = 30. More than 30 FD stations requires another wire path.

Burial Depth on New installations

Toro recommends that new installations have a minimum cover of 6" (150mm) on controller-to-decoder and decoder-to-solenoid cables. The irrigation plan may specify additional depth to be consistent with the depth of mainline or lateral pipe work and/or soil conditioning procedures such as aeration. Installation procedures must comply with all applicable local and national electrical codes.

Use only wire approved for direct burial if installing the wires underground without conduit. Splices must be accessible to facilitate troubleshooting and/or service.

Communication Cable to Power Cable Spacing

This recommendation applies to LAC communication installation. This minimum spacing to any power cable should be maintained to minimize the possibility of electrical interference which could affect the integrity of the LAC communication to decoders. If there are power cables already installed running next to the communication cables that do not meet the minimum spacing, remediation will be required to meet the minimum spacing listed in **Table 2** below.

Table 2	
Power Cable Circuit	
Rating	Recommended Minimum
(Minimum KVA*)	Spacing**
0-3	6 inches (15 cm)
3-10	12 inches (30 cm)
10-20	24 inches (60 cm)
20-50	36 inches (90 cm)
50-100	48 inches (120 cm)
>100	60 inches (150 cm)

*Maximum voltage x current rating of circuit

**These are minimum spacing recommendations to minimize noise coupling. There may be greater separation required by safety agencies or local codes.

Decoder to Sprinkler Wires

Wire Type - Should be copper conductors, solid core, with PE or PVC insulation, rated for at least 600V.

- 2.5mm² or 14 AWG Max. length is 275m (900')
- 1.5mm² or 16 AWG Max. length is 175m (575')
- 0.9mm² or 18 AWG Max. length is 122m (400')

Valve Compatibility

LAC is compatible with the same valves as GAC. Please see GAC Valve Compatibility section on page 20.

In addition, LAC is compatible with 102-4979 solenoids with spike guard protection. They were qualified in 1-1/2 inch P220 values at 200psi. They will also work with VIH. P254 one inch values using 9-6528 and 89-0878 solenoids should also work with a higher drive parameter (20V, 50ms, 5.1V).



Decoder Installation Steps

Decoders are installed along the two-wire path by connecting the blue wires from the decoders to the path using approved splice kits. Decoder output wires are spliced to solenoid wires. Use Toro-approved splices to properly water-proof all wire connections.

- 1. Secure the two-wire communication wires from a cable to terminals A1 and B1 or A2 and B2 of the SmartHub output board. Polarity does not matter. See **Figure 10**.
- 2. For new installations, route communication cable from controller to the decoder installation location. See communication cable length section for maximum lengths.
- 3. Decoders are recommended to be installed in a valve box. Record the decoder type and addresses found on the decoder. The address identifies the station(s) that the decoder controls.
- 4. Secure the communication wires from the two-wire path to the decoder blue wires using approved splices to make a water-proof connection. Polarity does not matter. If necessary, remove old decoders by cutting out splices. Make sure to cut wires back to remove any green or corroded copper.
- Route output wires from decoder to the solenoid. Make sure not to exceed the maximum length. Connect solenoids to decoder output wires using approved splices to water-proof connections. Wire colors are shown in **Table 3**. Each station or output has a maximum load of one solenoid unless it's an LAC-102, LAC-202, FD-102, or FD-202; they can have up to two solenoids.
- 6. See the LAC Decoder Surge Protection and Grounding section below if connecting decoders to earth. Four and six output decoders have built in surge arrestors with green-yellow wires that may be used for lighting surge protection.
- 7. Repeat steps 3-6 for additional decoders.

LAC Decoder Surge Protection and Grounding

Refer to the Earth Ground section (page 7) for protecting the controller. The following explains how to protect decoders:

Surge arrestors LAC- LSP are required to protect decoders from lightning. LAC-401 and LAC-601 decoders have an internal surge arrestor. The two blue wires connect to the two-wire communication path and the two green-yellow wires connect to earth through ground rods, plates or solenoid cores. One or both wires are attached to a copper grounding rod or plate. If the surge arrestors are located close to a Rain Bird green solenoid, then one wire can be securely connected to the core tube of the solenoid with a stainless steel nut, and the other to the grounding rod or plate. If not, then we recommend both green-yellow wires be secured to a grounding rod or plate. The ground resistance should be 50 ohms or less. If the resistance is greater than 50 ohms, more ground rods or plates should be added.

Install surge arrestors along the two-wire path so that there are no more than 8 decoders between them and there is no more than 500 feet (150m) of cable between arrestors (see **Figure 11**). This includes decoders with built-in surge arrestors. A surge arrestor should also be installed at the last decoder before a two-wire path terminates (dead ends). If the decoder is a 4 or 6 station decoder mentioned above, then the surge arrestor built into it can be used.

For site upgrades, replace existing surge arrestors with new LAC-LSP devices. For surge arrestors inside decoders, add an additional LAC-LSP device near it or replace the decoder with an LAC-401 or LAC-601.

A 5/8" by 8' (17mm x 2.5m) copper clad steel rod is recommended to achieve 50 ohms or less resistance. If multiple ground rod or plates are required, we recommend a minimum size of 10AWG ($6mm^2$) bare copper wires to connect them. A 5/8" (17mm) clamp or exothermic-weld fastener can be used to attach the green-yellow wire to the rod.

Table 3 - Wire Color							
LAC Decoder	Description		Decoder	Output (se	olenoid) W	/ire Color	
		Out 1	Out 2	Out 3	Out 4	Out 5	Out 6
LAC-101	Single station, single solenoid per output	white					
LAC-102	Single station, dual solenoid per output	white					
LAC-201	Two station, single solenoid per output	brown	white				
LAC-202	Two station, dual solenoid per output	brown	white				
LAC-401	Four station, single solenoid per output	brown	red	orange	black		
LAC-601	Six station, single solenoid per output	brown	red	orange	black	grey	white
LAC-LSP	Surge arrestor, no outputs						

All decoders connect to Two-Wire Path with blue wires. LAC-401 and -601 decoders have internal surge protection with two green-yellow wires for earth ground connections like the LAC-LSP.



16

LAC Motherboard Connections



WARNING: Before connecting any type of sensor or device, be sure the controller has been powered down.

🕅 LAC does not support sensors.

Switch Position

LAC motherboard switch position for Figure 12, A must be in "down" position.

Sychronization

Synchronization is not required for LAC.

Master Valve / Pump Relay

The Lynx SmartHub provides an output to control a master valve or pump relay. The output is active when any station is on, and off otherwise. Stations defined as switches do not cause the output to activate.

- 1. Connect the Positive/Hot wire of the power source that controls the master valve or the pump relay to the Master valve/Pump relay switch terminal. See **Figure 12, B**.
- 2. Route another wire from the Master Valve / Pump terminal and connect it to the master valve solenoid or pump relay.
- 3. Connect the Negative/Equipment ground wire of the power source to the master valve solenoid or pump relay.
- 4. Place the controller's power switch to ON.



GAC Decoder Installation

New System or New Communication Cable

AC station decoder modules are available in 1-station, 2-station, 4-station configuration or a Toro golf sprinkler with an integrated 1-station decoder.

The SmartHub pedestal and cabinet can accommodate either two or four daughterboards. An expansion unit is required to install the 2nd daughterboard. Each daughterboard has two output circuits. Each output circuit can handle up to 125 decoder modules (250 modules per daughterboard then) and 500 stations. The decoder modules can be connected in parallel anywhere on the two-wire communication line connected to the station terminals. Each station can activate up to two solenoids.

It is recommended that the decoder modules are installed in an approved valve box to provide easy access to the wiring. Use approved splice to waterproof all connectors.

Recommended Controller-to-Decoder cable: 14 AWG (2.5mm²), solid copper, jacketed 2-conductor, direct burial.

Burial Depth

Toro recommends that the Controller-to-Decoder and Decoder-to-Solenoid cables should have a minimum cover of 6" (150mm). The irrigation plan may specify additional depth to be consistent with the depth of mainline or lateral pipe work and/or soil conditioning procedures such as aeration. Installation procedures must comply with all applicable local and national electrical codes.

- Use only wire approved for direct burial if installing the wires underground without conduit.
- All field wiring splices must be accessible to facilitate troubleshooting and/or service.

Steps:

1. Route communication cable from the controller to the station decoder module installation location.

The maximum wire length between the controller and the decoder module is 6,800' (2072 m).

- 2. Secure the communication wires to terminal 1 of the SmartHub output board. Black wire onto the 1st terminal and Red wire onto the second terminal. See Figure 13.
- **3.** Install the decoder module in a valve box. Record the decoder module's address number found on the side label. This address number identifies the station(s) that the decoder module controls.
- **4.** Secure the communication wires to the decoder module's black and red wires. Connect the black communication wire to the black decoder module wire. Connect the remaining communication wire (red) to the red decoder module wire. Use approved splice to properly water-proof all wire connections.
- 5. Route output wires from the decoder module to the solenoid.

The maximum wire length between the decoder module and the solenoid are 400' (122m) for 18 AWG wire and 575' (175m) for 16 AWG wire.

- 6. Connect the solenoid wires to the decoder module's station wires. The station wires are color coded for easy identification (Station 1 = Violet, Station 2 = Yellow, Station 3 = White, Station 4 = Orange and Common Wire = Brown). Connect the solid colored (violet, yellow, white or orange) station wire to one of the solenoid wire. Connect the similar color station wire with black stripe to the remaining solenoid wire. Use approved splice to properly water-proof all wire connections.
- Connect an additional solenoid to the station wire as necessary.Each station has a maximum load of up to two solenoids.
- 8. Repeat Steps 3–8 for additional decoder modules.



Upgrade of Existing System, Using Existing Wiring for GAC

Communication Cable Type

Should be 2 or 3 copper conductors, solid or stranded, with PE pr PVC insulation, rated for at least 600V. For 3-conductor cables, the third conductor will not be used and any exposed ends must be capped and sealed with an approved splice.

Communication Cable Length

The maximum wire run from the SmartHub to the farthest decoder is 6800' (2072 meters) for 14 AWG (2.5mm²) cable. The total amount of wire path is 14,000' (4267 meters) for 14 AWG (2.5mm²) cable.

Resistance

The maximum resistance of the wire path with the end shorted can be 37.7 Ohms. The minimum resistance of the wire path with the end open should be 1000 Ohms.

Noise

For the wire path to be tested, disconnect from the DIU (or other controller), connect an oscilloscope across the wire path, and power up the pump and any other equipment that would be running when watering. Measure the voltage across the open wire path. It should be less than 1 V p-p.

Short Circuits

After the GAC decoders are installed, measure the resistance across the two open wire path wires to insure that it is still greater than 1000 Ohms to insure that no shorts were introduced during the installation process.

Communication Cable to Power Cable Spacing

This recommendation applies to GAC communication installation. This minimum spacing to any power cable should be maintained to minimize the possibility of electrical interference which could affect the integrity of the GAC communication to decoders. If there are power cables already installed running next to the communication cables that do not meet the minimum spacing, remdiation will be required to meet the minimum spacing listed in **Table 4** below.

Table 4	
Power Cable Circuit Rating	Recommended Minimum
(Minimum KVA*)	Spacing**
0-3	6 inches (15 cm)
3-10	12 inches (30 cm)
10-20	24 inches (60 cm)
20-50	36 inches (90 cm)
50-100	48 inches (120 cm)
>100	60 inches (150 cm)

*Maximum voltage x current rating of circuit

**These are minimum spacing recommendations to minimize noise coupling. There may be greater separation required by safety agencies or local codes.

Decoder to Sprinkler Wires

Wire Type - Should be copper conductors, solid core, with PE or PVC insulation, rated for at least 600V

Wire Length

For 16 AWG or 1.5mm2 – Maximum length is 575 feet (175m)

For 18 AWG or 0.9mm2 – Maximum length is 400 feet (122m)

Decoder Module Installation

Remove an old decoder by cutting out the old splices. Make sure to cut the communication wires and station wires back to remove any green or corroded copper. Strip the wires and connect a new decoder module per Figure 4. All splices must be made with approved splice kits.

Valve Compatibility

Toro	Colf VIH (Solonoid 80, 1005 or 118, 02/8)
	at 150 PSI
	400ft (122m) Max Solid Core, 18 AWG or 0.9mm2 Cable 2.3 Ohms/Conductor (400ft), 1 per Output
	575ft (175m) Max Solid Core, 16 AWG or 1.5mm2 Cable 2.3 Ohms/Conductor (575ft), 2 per Output
Toro	252 Valve (Solenoid 102-1905 or 118- 0248) at 150 PSI at AC Decoder, 1 per Output
Toro	220 Valve (Solenoid 102-0927) up to 220 PSI (passing is 150 PSI) at AC Decoder,1 per Output
Toro	216 Brass Valve (Solenoid 89-1673), Up to 220 PSI (passing is 150 PSI) at AC Decoder, 1 per Output
Rain Bird	Green Golf VIH Solenoid at 150 PSI 200ft Max Solid Core, 18 AWG or 0.9mm2 Cable 1.2 Ohms/Conductor, 1 per Output 328ft Max Solid Core, 16 AWG or 1.5mm2 Cable 1.2 Ohms/Conductor, 2
	per Output
Rain Bird	DV Solenoid (Black Wires) at 150 PSI at AC Decoder, 1 per Output
Rain Bird	PGA/PESB Solenoid (White Wires) at 150 PSI at Decoder, 1 per Output

Grounding GAC and DC Decoder Communication Cable

The lightning arrester (Toro P/N DEC-SG-LINE) is required to protect the decoder module from lightning. Without lightning arresters, decoders are vulnerable to lightning damage. For these arresters to discharge lightning energy efficiently, they must be properly grounded. To be effective, a resistance of 10 Ohms or less is recommended at each earth ground point. If the resistance with a single ground rod or plate is greater than 10 ohms, a second ground plate should be added. **Figure 14** illustrates the proper grounding and wiring of the arrester.

- 1. Locate decoder's power/communication wires (black and white wires).
- 2. Strip the insulation from lightning arrester's white wire and connect it to the white wires from the decoder and controller-to-decoder cable. Use approved splice to properly water-proof all wire connections.
- 3. Strip the insulation from lightning arrester's black wire and connect it to the black wires from the decoder and controller-to-decoder cable. Use approved splice to properly water-proof all wire connections.
- 4. Connect the lightning arrester's ground wire to the ground rod or plate's wire. If the ground rod or plate is not prewired, use a 10 AWG bare copper wire.

- 5. Drive a 5/8" by 8' (17mm x 2.5m) copper clad steel rod into well moistened soil not less than 8' (2.5m). For 2-Wire systems, install the ground rod adjacent to the communication cable (Figure 14). The top of the ground rod should be flush with or below ground level, and should be protected from damage using a valve box (A).
- 6. Measure the ground resistance per the instructions provided with the ground test instrument. A reading of 10 ohms or less is recommended. If the resistance is greater than 10 ohms, proceed to step 8.
- 7. Install a 4" by 96" (10cm x 2.5m) copper ground plate. The plate should be at least .06" thick (1.5mm) and should have a 6 AWG x 12' (10mm² x 4m) solid copper, insulated wire welded to the plate. The plate should go into a trench that is at least 30" (80cm) deep (B). Use ground enhancement material (GEM) per the manufacturer's directions. Connect the ground wire from the ground plate to the ground rod installed in step 5.



GAC and LSM Motherboard Connections



WARNING: Before connecting any type of sensor or device, be sure the controller has been powered down.

Sychronization

If there are two Lynx SmartHub controllers that are co-located or will have communication output wiring that is installed in a common trench or conduit, the controllers must be synchronized with each other for proper communication. Please see **Synchronization** insert on **page 29**.

Status Sensor

The Lynx SmartHub controller is designed to accept both a normally-open and normallyclosed status switch. For example, a pressure switch may be connected to this sensor input to detect pressure over a maximum value.

- 1. Route the status switch cable into the controller.
- 2. Connect the cable wires to the status switch terminals labeled A in Figure 15.
- 3. Place the controller's power switch to ON.

Rain Sensor

LSM systems can use either a rain bucket or a normally-open / normally-closed rain switch. GAC systems can use only a normally-open / normally-closed switch.

- 1. Route the rain sensor's cable into the controller.
- 2. Connect the cable wires to the Rain Sensor Terminals labeled **B** in **Figure 15**.
- 3. Place the controller's power switch to ON.

Flow Sensor

LSM systems can use either a Badger Meter / Data Industrial series 200 insertion type flow sensor or a Bermad 900 series flow meter.

- 1. Route the flow sensor's cable into the controller.
- 2. Connect the cable wires to the Pressure Sensor Terminals labeled **C** in **Figure 15**. Red wire to the + terminal, black wire to the terminal.
- 3. Place the controller's power switch to ON.

Master Valve / Pump Relay

The Lynx SmartHub provides an output to control a master valve or pump relay. The output is active when any station is on, and off otherwise. Stations defined as switches do not cause the output to activate.

- 1. Connect the Positive/Hot wire of the power source that controls the master valve or the pump relay to the Master valve/Pump relay switch terminal. See **Figure 15, D**.
- 2. Route another wire from the Master Valve / Pump terminal and connect it to the master valve solenoid or pump relay.
- 3. Connect the Negative/Equipment ground wire of the power source to the master valve solenoid or pump relay.
- 4. Place the controller's power switch to ON.









Lynx Communication Cable

Please note the following communication cable installation requirements and suggestions:

- The remote SmartHub is designed for use with shielded, twisted-pair, communication cable. Toro recommends R7162D or equivalent.
- More than one cable run can be connected to the Surge Protection Unit (SPU, part #35-7353).
- A remote SmartHub communication cable can emanate from another remote SmartHub connection.
- If additional communication cable runs are installed for future system expansion, each cable wire pair must be terminated with a 600 ohm resistor (Figure 15).
- If the communication cable is routed in the same trench as main power wires, or the SmartHub to decoder module cables, a minimum of 12" (30.5cm) separation is recommended to prevent voltage induction on the communication cable. Check local codes for actual requirements.
- Refer to the installation instructions provided with the central control system for communication cable testing procedures.
- If in-ground cable splices or repairs are required, the connection must be properly insulated with a waterproof splicing device. Using an appropriate splicing kit, such as Scotchcast 82-A1 (or equivalent), is recommended. Placing the cable splice in a small valve box for protection and accessibility is a good installation practice.

Steps:

Starting at the Surge Protection 1. Unit (SPU, part #35-7353), route the communication (comm) cable to each SmartHub leaving enough cable at each location to enable connection.

See Figure 16.

If additional communication cable is installed for future system expansion, connect a 600 ohm resistor across the wire pair at the end of the cable as shown in

Figure 17.

- 2. At the SmartHub, cut the cable and pull both ends into the SmartHub through the 3/4" (16mm) sweep conduit.
- 3. At the cable

ends, strip the outer jacket and inner insulation to expose the comm wires.

- Wallmount: Attach grey and yellow wires to Phoenix 3-hole connector, plug into modem port (Figure 18).
- Pedestal: Attach grey and yellow wires per Figure 19.



Communicating Between Lynx and SmartHub

A personal computer running Toro's "Lynx" software is necessary to communicate with the Lynx SmartHub. The SmartHub allows Lynx software to control over 9,000 sprinkler heads with individual precision.

The Lynx computer is attached to a Field Interface Unit (FIU) which sends commands to the SmartHubs throughout the golf course.

There are two ways for the FIU to communicate with SmartHubs: by Wireline or by radio. This document shows **three typical layouts** making use of one or both methods.

For the purposes of the layouts, the pedestal and cabinet Smart Hubs are interchangeable with each other.

Layout 1 - Local

The SmartHub is attached to the Field Interface Unit by a Wireline. The SmartHub typically resides in the office with the Lynx computer and FIU.



Connect grey and yellow wires as shown.

Layout 2 - Wired Lynx

The Field Interface Unit is attached to the SmartHub which is out in the field. Due to this distance (see note below), a Surge Protection Unit (SPU) is necessary on *both ends* of the cable run.



The Wireline connection is limited to about 9 miles.

Layout 3 - Wireless

The Lynx SmartHub DEC-RS-1000-DR (digital radio and modem) communicates with the Lynx computer via radio. The system is preconfigured at our production facility.



Communication Test Between Lynx and SmartHub

1. Launch Lynx.

Figure 20	Course 1 🗸 👌 Stop All	×						٥
~ · · · · · · · · · · · · · · · · · · ·	• Area	Diagnostic Operations			Online			
🚔 Daily Operation	Select by: O Hardware	Standard	Smart Hub		 Get Smart H 	ub Information		Start
		Express	O Set Mode		O Firmware			
🕅 Report Generator 🗸 🗸				\mathbf{h}	O Synchronize	field Date/Time		– /
ea.	` R	Operation Results		Ċ			Ď	E
💥 Utilities 🛛 🔨		Drag a column header here to	group by that column					م
Hand Held Test		Connection	Test Time	Entry Type	Hardware	Serial #	Station	Message
		RADIO Smi	art Hub 2:07:39 PM	Information	1			Begin Smart Hub Test
😳 LSM Diagnostics 👥		RADIO Sm	art Hub 2:07:42 PM	Information	1			Power On Time 14:04:00
		RADIO Sm	art Hub 2:07:43 PM	Information	1			Rain Hold is Off
(<u>e</u>) Sensor Dashboard	\neg	RADIO Sm	art Hub 2:07:43 PM	Information	1			Central Mode
		RADIO Smi	art Hub 2:07:43 PM	Information	1			Battery Health: Good
		RADIO Smi	art Hub 2:07:47 PM	Information	1			Battery: 3.18V
\mathcal{M} ravorites \checkmark		RADIO Smi	art Hub 2:07:47 PM	Information	1			Date and Time: 9/20/2022 2:07:06 PM
		RADIO Sm	art Hub 2:07:56 PM	Information	1			DB 1 amps 0.0000 volts 38.80
P THE CHINE		RADIO Sm	art Hub 2:07:56 PM	Information	1			DB 1 Black amps 0.0000 White amps 0.0000
		RADIO Smi	art Hub 2:08:04 PM	Information	1			DB 2 amps 0.0000 volts 38.80
		RADIO Smi	art Hub 2:08:04 PM	Information	1			DB 2 Black amps 0.0000 White amps 0.0000
		RADIO Smi	art Hub 2:08:40 PM	Information	1			Module Type is LSM
S Now Support		RADIO Smi	art Hub 2:08:40 PM	Pass	1			Smart Hub Test Result
	Included	RADIO Sm	2008-40 PM	Information Group by	1 Ungrouped *		F	Completed
	1 items selected							Activate Windows
								Go to Settings to activate Windows

- 2. Click LSM Diagnostics under the Utility bar (Figure 20, A).
- 3. Select the desired hub (Figure 20, B).
- 4. Select the **Smart Hub** button (**Figure 20, C**).
- 5. Select Get Smart Hub Information button (Figure 20, D).
- 6. Click **Start** button (**Figure 20, E**). Information should be displayed on the screen under "Message". It will show "Pass" or "Fail" for the Result (**Figure 20, F**), indicating if communication is working. Some models will show this result in a different color.



T

Radio range can vary. Under normal conditions, a range of two miles should be feasible. To boost radio range, mount radio antennas on masts.

If radio interference is a problem, please see the section below, "Changing the Frequency of the Radio".

Changing the Frequency of the Radio

At the time of installation, your authorized Toro installer should configure the radio to work properly. In the future, if it becomes necessary to change the radio frequency, there are two ways to change radio frequencies.

Radio installed in SmartHub

From the controller faceplate:

- 1. Press the 🚺 Diagnostics button.
- 2. Scroll to Radio Frequencies.
- 3. Use the arrow keys and Control Dial to adjust radio frequencies as needed.
- 4. Press 💼 Home when done to save settings.

Radio installed in FIU

You will need:

- Radio Manager software from Raveon
- USB to Serial (DB9) cable with included drivers
- 12V Phoenix power connector (from authorized Toro distributor)
- 12V power supply for radio (from authorized Toro distributor)
- 1. Disconnect all power to the FIU. Remove the radio. Place it next to the Lynx computer on a static-free surface.
- 2. At the computer running Lynx, install the drivers for the USB to Serial (DB9) cable. Reboot computer.
- 3. Plug USB cable into a USB port and Serial port on radio (**Figure 21**).
- 4. Connect Phoenix power cable into 12V power supply. Plug other end into DC IN port on radio (**Figure 22**).
- 5. Plug in 12V power supply.
- 6. Launch Radio Manager. See Figure 23.
- 7. Select appropriate COM port (Figure 23, A).
- 8. Change the baud rate to 1200 (Figure 23, B)
- 9. Press 'Discover Radio' button (**Figure 23, C**). The computer should discover the radio (**Figure 24**).
- 10. To see current radio frequency, enter **ATFX** into the command line (**Figure 25**).
- To change the frequency, simply add an appropriate frequency number to that command. Example: ATFX 460.5

UHF frequency range is from 450 to 470 MHz. Frequency number specified must be between those numbers.

- 12. Software will confirm the change (**Figure 26**). It is possible to manually confirm the change by simply typing in **ATFX** again.
- 13. Power down power supply and disconnect power line and serial cable.
- 14. Install radio back into FIU.
- 15. The UHF frequencies of the two radios involved (one in the FIU, one in the Lynx SmartHub) must match. Follow the above procedure with the radio from the Lynx SmartHub to specify a matching frequency.







Figure 25 Disconnect dio to Radio All Clear Updates Defaults 0K AIIO 0K AISL 6815083 0K ATSL 1200 8 N Auto Detect D64 0K ATTX T/R 460500000 / 460500000 0K ATTX 1200 8 N 0K Attrx T/R 460500000 / 460500000 0K ATTX

An FCC license is required to operate on any given UHF frequency. Frequency coordination (selection) is handled through the Personal Communications Industry Association (PCIA) (800-759-0300) and an application must be submitted to the FCC. There is a PCIA fee and FCC license fee that must be paid as well.

Synchronization (not used for LAC)

To synchronize two Lynx SmartHub controllers that are co-located or will have communication output wiring that is installed in a common trench or conduit, follow these steps:

- Step 1 Route a 2-wire cable (10' [3m] maximum length with a minimum diameter of 1.0mm² [18 AWG]) from the first controller to the second controller.
- Step 2 Connect the 2-wire cable into the Synchronization terminals of both controllers (Use either the PUMP or RAIN sensor terminals). Make sure that the wire polarity is the same (the wire connected to the left terminal on the first controller is connected to the left terminal of the second controller).
- **Step 3** Activate the sensor terminals being used for Synchronization (GW SYNC). See **Figure 28**.

The synchronization is achieved using a shared terminal with either the RAIN sensor or the PUMP PRESSURE sensor. To enable synchronization, the PUMP or RAIN sensor terminal jumper must be placed in the GW SYNC position (top two terminals).

Note: Sensor function is disabled for the terminal with GW SYNC jumper position. If the controller is utilizing both PUMP and RAIN sensor terminals, disconnect one of the sensors and install in the other controller with an unused sensor terminal.



SmartHub Operation

Modes of Operation

The Lynx SmartHub can be placed in three operating modes: Central, Local, and Off. In all three modes, the SmartHub will accept communications from Lynx[°]. Select the mode of operation by pressing **Unit Settings** and selecting **Mode**. Select from the three modes using the Input Dial ________.

Central Mode - When placed in Central mode, the SmartHub will water from irrigation lists, not programs. Irrigation lists are downloaded from the central; programs are not. Programs can be entered from the faceplate in all three modes, but will only water in Local mode. Central mode also allows Lynx to change most settings. If communication between central and SmartHub is interrupted for more than one hour, the Central Mode LED indicator will start flashing until communication is reestablished.

Local Mode - When placed in Local mode, the SmartHub will water from irrigation programs but not from lists. In Local mode, the SmartHub allows the central to set the date and time, but not affect programs or other settings that impact watering.

Off Mode - When placed in Off mode, the SmartHub will not execute any watering operation whether it is program or manually initiated. Any watering operation will terminate once the SmartHub is placed in Off mode. Watering operations will resume once the SmartHub is placed back to Central or Local mode. In Off mode, the SmartHub will allow the central to edit time, date and operation mode but will not allow modification of settings affecting irrigation programs.

Initial Setup

There are a few settings to establish before the SmartHub is fully operational. These settings are in the Unit Setting menu.

- Display contrast at the bottom of the menu may need to be adjusted to see the display properly.
- The language can be set. It has a flag symbol by it.
- CSG and Hub address must be set to communicate with Lynx.

General Editing

Pressing a menu key on the Lynx SmartHub will display menu items. Items with fields containing values that can be edited are called Entry Fields. Use the Arrow Keys $\bigcirc \bigcirc \bigcirc \bigcirc \bigcirc \bigcirc \bigcirc \bigcirc$ to navigate through the menus and entry fields. Modify any selected value by scrolling through the selection using the Input Dial _______. Values will be saved automatically when you exit an entry field or press another menu key. Pressing the Home is button will also save any modification and revert back to the Home display.

If no keypad activity is detected within five minutes, the SmartHub will automatically save any modifications and revert back to Home display.

Editing Large Values

When modifying large values, it can be time consuming to rotate the dial through all the values. Some three digit values can be changed by modifying each digit separately using the back arrow button. For example, a station number may be changed from 001 to 365 by the following procedure.

- 1. Press the back arrow twice when on the field for the station number. Only the first digit is now highlighted.
- 2. Rotate the dial to increase the first digit from 0 to 3. Now 301 is displayed.
- 3. Press the right arrow button to highlight the first and second digit. Rotate the dial to increase the first two digits from 30 to 36. Now 361 is displayed.
- 4. Press the right arrow button again to get all three digits highlighted. Rotate the dial to increase the value from 361 to 364.

Timing Mechanism Components

- 5. **Characterization Left and Right Arrows** allow you to select the next entry field within the same menu line. Any changes will be saved after you exit that entry field.
- 6. **Order the series of the se**
- 7. **Operation Mode LED Display** will indicate the current gateway operation mode.
- 8. LCD Panel is the display screen.
- 9. **_____ Input Dial** allows you to scroll through the value selection within the selected entry field.
- 10. **Home** button allows you to exit from any function menu and return the gateway to normal operation. After pressing the Home Key, all modifications to the settings will be saved.
- 11. **Manual Watering** button allows you to activate station(s), syringe, or program(s) manually. See page 39.
- 12. We Scheduled Watering button allows you to create an irrigation program as well as view the Station Based Flow (SBF) list, which is the automatic watering schedule downloaded from Lynx. See page 38.
- 13. **Diagnostics** button allows you to view the gateway's firmware version as well as other diagnostic information by rotating the dial through different options. See page 41.
- 14. If Station Settings button shows settings and data for each station. It shows the stations decoder address, activity for the day, if it's disabled or on hold, and if it is set as a switch. There may be other setting depending on the SmartHub model. See page 36 for more details. Modifications can be made here but can also be overwritten by Lynx.
- 15. Percent Adjust allows you to adjust run times at either the satellite, program, or station level. See page 36.
- 16. ► Start button will execute selected manual operation. See page 33.
- 17. **Description** Pause will suspend watering for a selected duration. The watering will continue after the duration.
- 18. **Stop** button will cancel currently running program(s) or station(s). See page 33.
- 19. **Unit Settings** button shows SmartHub settings such as the communication mode, rain hold duration, power mode, language, controller address, date and time, and display contrast. It also allows defaults to be reset for stations, programs, or the whole unit. Some settings can be modified here but may be overwritten by Lynx. A password may also be set to limit modification access throughout the timing mechanism. See page 34.



Power-Up Diagnostics

Upon power-up, the SmartHub will display:

Gateway TM Booting

The SmartHub TM will initiate a diagnostic test automatically during power-up. This function will take approximately ten seconds and it cannot be bypassed. If a problem is detected during the diagnostic test, it will be indicated on the display. The status information cannot be edited. The information is as follows:

Line 1: SmartHub Firmware Version and Revision Date

Line 2: Number and type of daughterboards detected

Line 3: Last Power Downtime Date and Time

Example:

Rev: 2.01p16,12/02/19

Detect: 2 DC DBoards PD 12/11/19 09:00:51

The default Home display will follow after the diagnostic display has timed-out. Home display example:

Sun 04∕02⁄19	05:57am
GW# 03:01−02	Sec: 57
Day Change:	03:00pm
Next Start:	06:00am
Lynx Smart Hu	b LSM

Home Button

Pressing the Home button will revert to the default display. When editing irrigation programs, Station or SmartHub settings, pressing the Home buton will save any setting modifications and return the user to the Home display. Home display examples:



The GW# line displays the address of the controller. In the example above, the address of the SmartHub is Group 3. The address of the first station board is 01. The second station board address is 02.

The Day Change line displays the next program start time (Next Start: HH:MM) if the current day is an active watering day. If the SmartHub is running a program, the Day Change line will display **Running XX programs** to indicate the number of active programs.

If the SmartHub has an active running program, the display will read:

	Sun 04/02/06 GW# 001-001 Puppipg 04	02:31pm Sec: 57	
--	---	--------------------	--

P01	Sta01	%00:05:00	(The "%" symbol before the runtime indicates that station 01 is percent adjusted.)
P01	Sta02	00:05:00	(P01 indicates Program 01 is currently active)
P01	Sta03D	00:05:00	(The "D" symbol after the station number indicates that station 03 is disabled.)
P02	Sta10P	00:05:00	(The "P" symbol after the station number indicates that program 02 is paused.)
Man	Sta21	00:10:00	("Man" indicates Manual Watering is currently active)
Man	Sta22S	00:10:00	(The "S" symbol after the station number indicates that program 02 is stacked.)

Start Button

Use the Start button to execute either an irrigation program, a Multi-Manual operation, or a Syringe. These are explained fully in the Manual Watering section, page 31.



Press the Stop 🔳 button to cancel.

Pause Button

II The Pause button can be used to pause any running irrigation program or all irrigation activity.

```
Pause : Prg: 01
for : 00 hr 05 min
Press () to start
00 Programs paused
```

Stop Button

Use the Stop function to cancel all irrigation (pictured), an active program, an individual station, a manual operation, or even a switch. If the Lynx SmartHub has no current activity, pressing the Stop button will have no effect. The Stop function causes a system cancel including power-down / power-up sequence for ALL daughterboards regardless of station activity.

Cancel : All Watering
Press 🔳 to Cancel
Running 01 programs
P01 Swh01 00:01:00
P01 Swh01 00:01:00

Unit Settings

Unit Settings allows you to set SmartHub parameters such as Time, Date and Language.

- Use the Up or Down Arrows \diamondsuit \diamondsuit to navigate through the menus.
- Use the Left and Right Arrow 🔷 🔷 to advance to the next entry field on the same menu line.

Command Function Comm Mode: Use this menu item to select the SmartHub mode of operation between Central, Local or Off mode. Hold All: This setting prevents scheduled watering from starting when set to a duration. The duration can be set to Today, 2-30 days, Permanent, or None. The setting does not cancel manual watering or prevent manual watering from starting. Hold Rain: This setting cancels all watering and prevents scheduled watering from starting. The duration can be set to Today, 2-30 days, Permanent, or None. Manual watering can still be started during rain holds. Rain hold does not affect stations defined as switches. **Reset Prg's:** This command resets all programs by selecting Yes All. After selecting Yes All, press the Up or Down Arrows 🔷 📀 to activate. There is a short countdown before the command executes during which the command can be cancelled.



All program settings will be erased after a successful reset.

Reset Sta's: This command resets all station settings by selecting Yes. After selecting Yes, press the Up or Down Arrows 🔷 🔷 to activate. There is a short countdown before the command executes during which the command can be cancelled.



All station settings will be erased after a successful reset.

Reset Unit: This command resets the SmartHub settings by selecting Yes. Select Yes using the Input Dial 🔭 and press the Up or Down Arrows 🔷 🔷 to activate. There is countdown during which the command can be cancelled before the SmartHub reboots.

Reset All Defaults 10	
STOP to escape	



Resetting the unit will erase all user-defined program data and configuration values in the SmartHub's memory.

Power Mode: This setting shows the power mode as "Switched" or "Continuous". We recommend "Switched". LAC will have a 50Hz short finding option to read current with clamp meters. It will automatically time out. The duration left in this mode is shown on the home screen. LSM System:

This sets the type of decoders attached to the SmartHub controller. Options: Yes or No. The selection is set to Yes if all decoders on the SmartHub are LSM. (DC systems)

Send OFFs: (Not available on LAC systems.)	This setting will send an extra OFF command when a station or irrigation program is stopped or ends. Options: Yes or No. We recommend No.
Enable Sta's:	This setting resets all disabled stations with one execution. Select Yes All using the Input Dial , and press the Up or Down Arrows $\bigcirc \diamondsuit$ to activate. Select No to cancel. Individual stations can be enabled/disabled by using the Disable function within the Station Settings menu.
Language:	This selects the language that shows on the display.
Clock Set:	This sets the current time. Use the Left and Right Arrow Keys 🔶 🔶 to select the Hours and Minutes parameters then use the Input Dial+ to modify the values.
Clock Mode:	Use this menu item to select the clock mode between Am/Pm (12-Hour) and 24-Hour mode.
Date Mode:	Use this menu item to select the date mode: MMDDYY or DDMMYY.
Date:	This sets the current date. Use the Left and Right Arrow Keys 🔶 🔶 to select the Month, Date and Year parameters then use the Input Dial+ to modify the values.
Day Change:	The Day Change time is the time that the SmartHub will advance to the next irrigation day. The default day change is 12:00 am. Adjusting it allows programs to start throughout the night on the same active day schedule. Programs with runtimes beyond the day change time are allowed to finish.
CSG Address:	This sets the CSG (Central SmartHub Group) address. Lynx uses this address to identify different SmartHubs. Each hub should have its own unique CSG address; ie, hub 1 is CSG1, hub 2 is CSG2, etc.
SAT Address:	This sets the station group address. It is the value of the first station group number.
Sta Delay:	This sets the delay in seconds. It is the minimum delay time between a station turning on and the next one turning on. It is also the delay between a station turning off and the next one turning off. The feature helps avoid water hammer. Note that there is an inherent delay due to messaging even if the delay is set to zero.
Max Sim Sta:	This sets the maximum number of simultaneously operating stations. This threshold will be applied to all programs and manual irrigation functions. Each program can be set with a lower limitation if necessary. This setting is set in Lynx and downloaded to the SmartHub.
Set Password:	Use this command to set a password to prevent unauthorized access to the menu system. The menu system can still be reviewed but no values changed.
Display Adj:	This setting adjusts the contrast of the LCD screen. Use the Input Dial+ to darken or lighten the text display.
Chk Ovrload	This setting checks that the current and voltage along the wire paths is sufficient before activating a station. If not sufficient, the controller will not allow the station to turn on. This setting should not be changed unless directed to.
LAC Speed:	The setting indicates how fast LAC type decoders communicate. It can be set from 1 to 4. The default is 3 and should not be changed unless directed to. The setting is only for LAC SmartHubs.
LAC coil:	The setting indicates when certain error checks are made when turning the station on or off. It defaults to check when stations turn-off (down arrow) and should not be changed unless directed to. The setting is only for LAC SmartHubs.
FD coil:	The setting checks FD type decoder solenoids when stations turn on. It is enabled by default. The SmartHub will not detect FD type decoder errors if disabled. The setting is only for LAC SmartHubs.

% (Percent) Adjust

The percent adjust function allows you to fine tune irrigation programs, stations, or the satellite as a whole (as in, all Programs and all stations connected to the satellite). With weather conditions changing constantly, Percent Adjust allows you to tune runtimes in your system easily without changing all the runtime values individually in the program.

Use the arrow keys and Input Dial to modify percentage values for the Satellite, selected program, or selected station.

Percent A	djust	
Satellite		100%
Program:	PØ1	100%
Station:	S001	100%

Percent Adjust does not affect manual operations or scheduled list activity.

Station Settings

■ Station Settings allows you to set parameters specific to each station as well as access the Sensor Setup Menu for setting up a Rain or Flow sensor.

- Use the Up or Down Arrows \diamondsuit \diamondsuit to navigate through the menus.
- Use the Left and Right Arrow Keys 🔷 🔷 to advance to the next entry field on the same menu line.
- Use the Input Dial _______ to select values when editing.

Command Function

Sensor Setup Menu (Sensors only available on LSM systems.)	Access the Sensor Setup menu by changing the board number. The Sensor Setup menu is accessible for <i>editing</i> when the statellite is in Local Mode and Off Mode. If satellite is controlled by a Lynx Central computer, this menu is available for <i>review</i> only.	Sensor Setup Menu Input: 1 Type: FLOW I_WTW : 12:00pm O_WTW : 11:59pm I_Min : 00000 gpm I_Max : 00000 gpm	
	to (see page 16). Next, select the type of sensor, either	Sensor Setup Menu Input: 2 Type: RAIN	
	RAIN, STAT, or FLOW. Input 1 only accepts flow sensors.	Tip : 0.01 in Max : 00.00 in	
	Input 2 can accomodate either STATUS or RAIN sensors. Finally, configure sensor settings, such as whether a	Units : English(in) Alarm : Off	
	sensor is Normally Open or Normally Closed, the tipping point on a rain bucket sensor, whether a sensor generates an alarm or not, what activity will follow if a station does generate an alarm, and more.	Board 1 Sat 001-001 S001 100% Dec Addrss: 174F42	
Board	Select the daughterboard, 1 or 2.	Group 001-001, 001-1 Sched today 02:20:00	
Sat	Displays the address of the currently accessed daughterboard. This value cannot be changed.	Water today 00:13:00 Water yestr None Disable : No	
Sta	Station Setup screen.	Hold Sta : None	
	Select the station to edit in this field. Choose from Station 01 through the SmartHub	Is Switch: No	

	LAC Station Setup screen is pictured at right. 733218 is the drive parameter in hexadecimal for Station 1. These values are set in Lynx and loaded into the SmartHub along with the address when mapping. 73 represents an activation voltage of 16V. 32 represents an activation time of 50ms. And 18 represents a hold voltage of 2.4V.	Station Setup S001 100% LAC-102 Dec Addrss: 2000064 Dec Output: 1 733218 Sched today 00: 10:00 Water today 00:12.06 Water yestr None Disable : No Hold Sta : None Is Switch: No
%	This is the percent adjust of the selected station. 100% means that it is not adjusted. The adjustment does not affect list or manual watering.	
Dec Addrss:	Decoder module addresses are downloaded from Lynx ar Lynx will overwrite address changes in the TM when ma	id can be entered or changed at the faceplate. pping.
Group	Displays the express group numbers assigned to a station that allows it to work with express tests. If it says "LSM not assigned," then the station will not work with express tests. The assignment occurs when a station's address is changed and is not zero. Group express numbers only work for LSM systems.	
Sched Today:	Total scheduled station runtime for the current irrigation	day.
Water Today:	Total station runtime that has occurred for the current ir	rigation day.
Water Yestr:	Total station runtime that occurred for the previous irrig	ation day.
Disable:	A disabled station will countdown as if it is running, but will not turn on. Disable station operation by selecting Yes . Enable station operation by selecting No .	
Hold Sta:	Use this menu item to skip scheduled operations for this time. Select the hold duration from 01–30 days , Perman operation.	station or switch for a specified period of nent or None . Holds do not affect manual
Is Switch	A station output can be configured as either a station or s motherboard pump output on and will turn off during ra	switch. A running station will turn the ain holds. A switch will not.

Scheduled Watering

Scheduled Watering consists of watering from locally-scheduled programs in Local Mode or watering from the SBF list in Central Mode.

Central Mode

Lists downloaded from Lynx will water in Central mode. Programs will not. Lists cannot be edited at the faceplate. See the **Station Based Flow Management** section on the next page for viewing the downloaded watering list from Lynx.

Local Mode - Programming a Program

- 1. Select the **Program** number.
- 2. Select a **percent adjust** number.
- 3. Specify a **hold** from zero to thirty days, or even permanent.
- 4. Select the **type** of irrigation program:
 - **Basic**: Irrigation is activated every day at the specified time for the specified duration.
 - Advanced: Irrigation occurs at specified intervals from 1 to 30 days (2 days pictured) or by selecting individual days over a two week period.
- P01 100% 00:01:00 Hold: None Type: Advanced Water Every: 02 days Today's Day: 01 Start :*01 09:07am Syringe: 01 min Repeats: 0 Soak : --:--:--Sat01 001-001 1:00 Sat01 0 ----- --:--Simult : 001
- **Grow In**: A Grow In program is a user-defined additional irrigation cycle that runs in addition to the regular irrigation schedule. This is typically done when plants, trees, or lawn need extra water. A new sod lawn, for example, would benefit from a grow-in program for a couple of weeks or month.
- 5. For interval schedules, it is necessary to define **today's day** number. As in, if you specify a five day interval, and specify today's day as day 3, then the five day interval will start in two days.
- 6. Specify a Start time.
- 7. An optional Syringe time can be specified. (A syringe operation is a specific user-defined programmed additional "injection" of water into the normal irrigation cycle. A syringe operation might be scheduled to cool artificial turf on a hot day, for example.)
- 8. Specify a Repeats number. This is the number of times a syringe operation will run, separated by Soak times.
- 9. An optional Soak time may be specified for programs. This is a delay between programs that repeat. It gives the water a chance to soak into the soil without running off.
- 10. Set run times for individual stations attached to the satellite.
- 11. Specify a Simultaneous number. This is the number of stations that will run at one time during the program. Stations run in the order of station number.

Station Based Flow Management:

To review the SBF (Station Based Flow) list, access the SBF screen from the Scheduled Watering menu.

Follow the steps to access.

The SBF List is only available after a successful download from the Central computer.

There can be two lists in a LSM/GDC controller. They are accessed by arrowing to the right and adjusting the Sat field. For example, Sat01 is the first list that runs stations from the first daughterboard, and Sat02 is the second list that waters stations from the second daughterboard.

- 2. Use the Right arrow \blacklozenge to navigate to the event number.

SBF (Station Based Flow) Sample Screen:

SBF List B	Event 001	(1st line will indicate the Event Number)
Start 12:	00am S22	(2nd line will indicate the Start Time followed by the Station Number)
Run 00:1	.0:00 P26	(3rd line will indicate the Runtime [Hrs:Min:Sec] followed by the Program Number)
Program St	art (80)	(4th line indicate Miscellaneous Functional Code)

Editing the SBF List is not allowed at the SmartHub. SBF modifications must be made at the Central computer and downloaded to the SmartHub to implement changes.

SBF Lists are disabled from watering when the controller is in Local Mode.

Manual Watering

There are three types of watering that can be manually started: Program, Syringe, and Multi-Manual. Manual watering may be started in the Local or Central mode.

Start Program - Use this command to manually activate an entire irrigation program. The irrigation program must of course already be configured correctly to manually activate one. A program on hold can still be manually activated.

- 1. Press the Manual Watering Key 💾.

- 4. Press the Start Key **b**. Irrigation begins immediately.

Syringe - Select a Syringe program to activate all stations in a selected irrigation program for a specified runtime.

- 1. Press the Manual Watering Key 💾
- Press the Down Arrow to move to the Runtime field.
 Use the Input Dial ______+ to specify the desired runtime in minutes.
- 4. Press the Down Arrow to move to the Program field. Use the Input Dial ______+ to select the program to run.
- 5. Press the Start Key **>**. Irrigation begins immediately.

ram for a specified runtime.

Manual : Start Prog

Press 🕟 to start

Program: 01

Manual : Syringe Runtime: 01 min Program: 01 Press **>** to start M-Manual - Select M-Manual to activate a station or group of stations with a specified runtime.

Multi-Manual Station Activation Directions

Manual station activation example: Activate stations 1-12 with a runtime of 5 minutes each and limit watering to 3 stations simultaneously.

- The Multi-Manual function is limited to the maximum simultaneous station settings of the SmartHub. In cases where a program is running and a multi-manual activated, the SmartHub will activate all stations specified in the multi-manual in addition to the currently activated stations. Thus, the multi-manual will allow the SmartHub to exceed the maximum simultaneous station settings.
- 1. Press the Manual Watering Key 🖤.

Manual ; M-Manual Sat01 001-012 00:05 Simult : 003 Press ▶ to start

- 3. Press the Down Arrow to advance the cursor to the Sat#: field.
 Use the Input Dial _______t to select the correct value of the station group or daughterboard or satellite to run.
 Use the Right Arrow to advance the cursor to the first station of the range to run. Use the Input Dial ______.
 to select the correct value of the first station being irrigated. For this example, select station 01.
- 4. Press the Right Arrow \clubsuit to advance the cursor to the last station of the range. If irrigating only one station, this value should be the same as the first value. For our example, select station 12.
- 5. Press the Right Arrow \clubsuit to advance the cursor to the next entry field. This entry field will indicate the runtime in hours and minutes (HH:MM). Use the Input Dial _______, and the Right Arrow Key \clubsuit to select the appropriate runtime value. For our example, set the value to 00:05.
- 6. Press the Down Arrow < to advance the cursor to the next entry field. Notice that a new Station: line was created. Fill this line only if irrigating a second range of stations. Otherwise, leave this line blank.
- 7. Press the Down Arrow 🔷 to advance the cursor to the Simult: field. Use the Input Dial ______+ to select the maximum simultaneous irrigating stations. For this example, set the value to 03.
- 8. Once finished, press the Start Key ► to activate.

To cancel, press the Home Key 🛋 . The screen will revert back to the default display.

Pressing the Home Key saves the entered values.

The SmartHub containing the desired station to be started can be selected by highlighting 'x' in the "BDx" field.

When reviewing the Multi-Manual program by pressing the Manual Watering button, the display removes the stations that watered or are currently watering from the list.

Modifying the Multi-manual appends the added stations to the currently running manual operation. Currently running stations are not affected. The SmartHub runs the stations in sequential order, disregarding the order in which the stations were entered.

Diagnostics

IX The Diagnostics function of the remote SmartHub allows for easy system troubleshooting. Within this function, the user can monitor the SmartHub's internal voltages as well as check the firmware version.

Manas I infa Manitan	Maninana anno 1995 an barrana Iana an I	
Menu: Link Monitor	the SmartHub.	Menu: Link Monitor
		Naks: 000 Msg#: 000 FE: 000 Other:000
Menu: System Monitor	Monitors communication between Lynx and all SmartHubs in the system.	
Menu: Revision	Displays the SmartHub firmware version and creation date.	Menu: Revision
	Scroll down to view the motherboard firmware version as well. The daughterboard version is also available on some platforms.	Revision: 2.01p09 Rev Date: 10/9/19 GWY FL Ver 1.0 10/04/12 TM Hardware Ver: 1
Menu: PowerUp Detect	Displays the number of detected stations and the number of detected sensors. It will also display the date and time of the last power- down (PD) and last power-up (PU). Press the Down arrow \bigstar to scroll down through the informations.	Menu: PowerUp Detect DC 2/500 DB[1,1,0,0] PD 01/11/19 14:22:20 PU 01/12/19 09:57:24 I2C Events : 000 000 Reset Type : 09 Wire line found: No Radio Anlg Enbl: No
Menu: Stations Alarms	Displays problems detected when turning on and off stations. The example to the right shows a communication problem for station 2 on an LAC system. Detailed information for each alarm can be found by rotating the knob in the station number field. The last inverted line on the bottom automatically changes every second to display all stations with alarms.	Menu: Station Alarms Brd 1 Sta 001 * (001) Bad Comm. (TvTO 5) 09/22/22, 10:23 LAC Clear Alarm: No Sta 1-004 Solenoid
	Alarms may not show if Lynx reports them and then clears them. Station alarms may automatically clear each irrigation day on some systems.	
Menu: Station Last On (LSM only)	Displays the time, date, current, and voltage of the last activated station.	
Menu: Sensor Monitor (LSM only)	Displays real-time sensor information for all enabled sensors. Scroll down to review Rain Today, Rain Yesterday, and Rain Window amounts.	Menu: Sensor Monitor Hub Sensors Inpt 1 Flow: 98.15gpm Inpt 2 Rain: 00.20in Inpt 3 Stat: CLOSED

Lynx[®] SmartHub Installation and User Guide

Menu: VA Monitor	Allows user to monitor the SmartHub's amperage, voltages and temperature in real-time. This would be used when troubleshooting the SmartHub's internal circuit voltages.	Menu: VA Monitor Battery: 3.2V LCD: 27C VL:-3.5V
Menu: DB Monitor (for LSM)	Displays the voltage and amperage of the daughterboards attached to the motherboard, as well as the amps for L1 and L2 (black and white respectively) terminals.	Menu: DB Monitor DB1 DB2 Volts 38.8V None Amps 0.000A L1 0.000A L2 0.000A
DB Monitor (for LAC)	Besides voltage and current, LAC will show if the power is on, off, or in 50Hz short finding mode. Each set of DB terminals has a relay that is turned on when in use. The examples shows Path 1 and 2 are both on. They can individually be forced off here for troubleshooting.	Menu: DB Monitor Power = On 14:46:29 Paths = 1 On 2 On Volts = 41750 mV Amps = 7 mA (1) State = Operating 00
Menu: Event Codes	Displays the SmartHub's Event Code log. You can clear the log from this option. Navigate to the Clear field using the Down arrow, select Yes using the Input Dial	Menu: Event Codes Clear log: No Last Code: 131, 005 01/12/12, 09:37:20
Menu: Decoder Communications	Displays real-time communication data between the TM and decoders.	Menu: Decoder Comm. Sent: Rd Flow Bd1 Resp: Ok Total bad Resp: 000 Total Timeouts: 000 Clear Totals : No
Menu: Decoder Diagnostics	This command allows the user to run diagnostic tests that send messages to decoders and modules. The foculate will show the last	
Note: Tests marked with an asterix (*) are for GAC only.	 and modules. The faceplate will show the fast test performed at the TM. The tests include: communication (pictured below) solenoid (pictured below) LSM voltage 	Cable Resistance (pictured below) * Decoder Output * Decoder Version * DBoard Output *
LSM-only tests are marked as such	 LSM amps LSM version LSM Hardware Errors 	 DBoard Version * Solenoid Resistance † Get Solenoid Drive †
Tests marked with a cross (†) are for LAC only.	 LSM Grp02 Into LSM Grp16 Info LSM Group Ping Group Volts Group Amps Group Errors Group Sta's On LSM Grp Charge Fail 	Learn Solenoid Drive † Cable Resistance (to decoder) † LAC Input Voltage † LAC Version † LAC leakage Amps † LAC Temperature † Factory Reset † Get LAC Object † Discover LAC address †

Menu: Decoder Diag Communication Brd 01, Sta 001 Press D to start 34.78V 0.14A Status: 03 DONE	-	Menu: Decoder Diag. Solenoid Brd 01, Sta 001 Press 🕑 to start Result: 00 Out1 OK Status: 03 DONE	Menu: Decoder Diag. Cable Resistance Brd 01, Sta 001 Press ▶ to start 1.25V/0.31A = 4.1Ω Status: 03 DONE
Menu: Radio Tx Chars	This mo to anot	enu item transmits numerical sequences her radio for troubleshooting purposes.	
Menu: Radio Ping	For this an addr from th satellite same fro commu	s menu item to work, the radio needs ress. The radio address is generated the Satellite address. The radio within the and the target radio must be on the equency. The number returned is the unication time between the radios in ms.	
Menu: Radio Information	Display	rs information about the installed radio.	Menu: Radio Info. Model #: RV-M7 Version E28 Serial # 15241181 Last RSSI -dB Get more: no
Menu: Radio Settings	Display consum or not. Indicati	rs the radio address, power aption, and whether RSSI is enabled RSSI is Received Signal Strength ion.	Menu: Radio Settings Radio Power: 040% Radio Addr: 1181 RSSI Enable: No Set Radio Dflts: No
Menu: Radio Frequencies	Display frequen from th	rs the radio's send and receive ceies. The frequencies can be adjusted is screen.	Menu: Radio Freq's Channel: 1 Rx Freq1 465.5000MHz Tx Freq1 465.5000MHz
Menu: Message Log	Display The Me this scre	rs the logged messages. essage Log history can be cleared from een as well.	
Menu: Link Settings	View th A coupl whether If a radi set here	he SmartHub's communication settings. le of parameters, such as lead time and r there is a radio or not, can be edited. io is used, the Radio Setting should be for it to work correctly.	Menu: Link Settings Lead (On): 030ms Hang: (Off): 010ms Baud Rate: 1200 Radio: Digital (Dig) RSSI Enable: No
Menu: TW Day Info (LAC only)	Shows u alarms o is not al showing lowest v	up to four two-wire daughter board during the irrigation day. The last line larm informationit alternates between g the highest two-wire current and voltage recorded for the irrigation day.	Menu: TW Day Info. Alarm 1 TW Overload Code: 0x00 15:07:40 Clear Alarms: No (2) 37.96V at 15:06:54

Lynx[®] SmartHub Installation and User Guide

FD Test LAC Communication Test and LAC Solenoid Test	There is one test available for FD type decoders. This checks both the communication and solenoid and is available in Lynx. The test will fail if the solenoid is not connected. LAC type decoders have separate communication and solenoid tests. The communication test checks if the hub can communicate with decoders. It does not require solenoids and will not cause watering. The LAC solenoid test checks the solenoid for opens and shorts. If the SmartHub cannot communicate to the decoder during the test it will fail and say timeout. Both tests are available in Lynx but results may	Menu: Decoder Diag. Communication Brd 01, Sta DE Press to start Result: 18 PASS Status: 03 DONE
Solenoid Resistance	show a different failure if the SmartHub cannot communicate to a decoder. Retrieves the coil resistance determined when the station was last turned on. This is for an LAC type decoder.	Menu: Decoder Diag. Solenoid Resistance Brd 01, Sta ØØI Press D to start 23Ω, 62mH Status: 03 DONE
Get Solenoid Drive	Reads a LAC decoder's drive parameters.	
Learn Solenoid Drive	Learns a LAC type decoder's drive parameter. We do not recommend using this. It can be	
Cable Resistance	overwritten and may cause brief watering. Determines cable resistance from the SmartHub to a LAC type decoder.	Menu: Decoder Diag. Cable Resistance Brd 01, Sta ISI Press ▶ to start 54Ω Status: 03 DONE
LAC Input Voltage	Determines the two-wire voltage at the input of AC decoder	
LAC Version	Reads a LAC decoder's firmware version.	
LAC Leakage Amps	Determines the ground leakage on the solenoid side of a LAC decoder station	
Discover LAC Address	This will read the address out of a LAC decoder when it's the only one attached to the SmartHub.	
LAC Temperature	Reads a LAC decoder temperature in Kelvin.	Menu: Decoder Diag. LAC Temperature Brd 1, Sta 001 Press to start 297.10° K Status: DONE
Factory Reset	Resets a LAC decoder. Not intended for normal operation.	

Motherboard Diagnostic Display

The motherboard display and buttons are useful for models that do not have Timing Mechanisms. The SmartHub motherboard (LSM shown) features a 2-line, 16 character LCD display (A) for quickly viewing for system diagnostic information. Use the - and + buttons (B) to scroll through the display lines and available options and the ENTER button to clear alarms when prompted.

All screenshots below are for the LSM motherboard.



After power up, the screen will display board's firmware version. Rev 10.1.3 11/13/2019 After the initial Revision screen, the display will show the D1 = OFFD1=0.024 38.6V real time current and voltage for both daughterboards if D2 = OFFD2=0.024 38.6V they are on. The display will also show the load currents by individual D1L1=0.24A D2L1=0.24A wires of a two-wire communication line. D1L2=0.24A D2L2=0.24A The display will show the Rain and Pump Pressure sensor state followed by count and will 1 open 0 be updated in real time. 2 open 0 The display will show the information contained in the message during transmission Tx: ----execution. The information will only be displayed while the transmission is being Rx: ----executed. The display will refresh if a different command is transmitted. The display will show the time and date. 10:47:18 11/21/2019 The display will show the real time pulse frequency of the flow sensor input. Flow = 00.00 Hz

Note regarding GAC motherboards: The GAC motherboard display operates similar to LSM except that it shows currents and message commands to four GAC daughterboards. GAC also shows the current for both phases of the AC signal. Most information is also available using the timing mechanism. All models have the firmware version and ability to adjust the display contrast.

Alarm Conditions

All of the Alarm Conditions, when active, toggle back and forth between the two message states below.

Thermal Alarm

D1 Thermal D2 A=0.500	•	Shuts off and dis Motherboard LO
		the daughterboa
Hold Entr to Clr D2 A=0.500	•	Affected daughte

Amp Limited Alarm

- Shuts off and disables daughterboard indefinitely.
- Motherboard LCD toggles alarm and instruction on how to re-enable the daughterboard.
- Affected daughterboard's alarm LED blinks on and off.

If a wiring issue causes excessive power consumption (> 1.65 Amps), the SmartHub limits the voltage to 6V which prevents system shutdown and allows for troubleshooting.

D1 Amp Limited D2 A=0.500	Triggered when individual daughterboard's load current is above 1.0 Amps.Does NOT shut off or disable daughterboard.		
	• Motherboard LCD toggles alarm and instruction on how to clear the alarm.		
D1 A=1.100 D2 A=0.500	• Affected daughterboard's alarm LED blinks on and off.		
Phase Current			
Imbalance Alarm	• Triggered when load current of one wire is 2x higher than the opposite wire		
D1L1 High Amp	for a minimum 20 seconds.		
D2 A=0.500	• 20 second timer is reset when load current of one wire is no longer 2x higher.		
	• Does NOT shut off or disable daughterboard.		
D1L1 A=0.750 D2 A=0.500	• Motherboard LCD toggles alarm and instruction on how to clear the alarm.		
	• Affected daughterboard's alarm LED blinks on and off		



The display difference between the **High Current Alarm** and **Phase Current Imbalance Alarm** is subtle: Notice the two-character difference in the display on the first line: "D1" (High Current Alarm) vs. "D1L1" (Phase Imbalance).

Clear Alarms

To clear any of the above alarm conditions, hold ENTER to clear the alarm.

Specifications

Radio

Equipment Type – Data radio, Raveon RV-M7-UC

Frequency Band – UHF

RF Output Power – 2.0 watt

Current Consumption:

Standby (Muted) – < 65 mA

Transmit 2 watts RF power – < 1.0A FCC License: FCC ID# SRS-RV-M7-UC

Note: Radio not included with LAC.

Fuse and Circuit Breaker

Power Supply (for pedestal configurations only):

1.5A On/Off Switch/Circuit Breaker – Main Power Input 3.2A Fuse (Slow-Blow) – Field Output

Output Board (for LSM only): 3.2A Fuse

Lynx SmartHub

- **Cabinet**: Non-corrosive, lockable wall mount, indoor/outdoor installation
- **Pedestal**: Non-corrosive, lockable pedestal, indoor/outdoor installation
- Six 1" (25.4mm) conduit openings and one 1 1/2" (38mm) conduit opening
- Controls up to 1000 stations (800 for LAC)
- Rated Input Voltage: 100-240 VAC, 50/60 Hz
- Rated Output Voltage: 40VAC (42.2VAC for LAC)
- Rated Input Current: 1.6A
- Rated Output Current: 1.8A max. (1.1A for LAC)
- **SmartHub output power**: 75W max.
- Automatic Action: Type 1.C product Impulse Voltage: 2500V
- Altitude: 2000m max
- Ingress Protection: IP44
- **Operating Temperature:** 0°C to +60°C (32°F to 140°F)
- **LAC:** 0°C to +50°C (32°F to 122°F)
- Storage Temperature: -30°C to +60°C (-22°F to 140°F)
- Ball Pressure Test Temperature: 257°F (125°C) Glow Wire Test Temperature: 1,562°F (850°C)

Warranty and Agency Statement

Warranty

The Toro Company offers warranties for golf product. Please see the current catalog at the time of installation for warranty information.

FCC / IC / EMC Statement

North America: This equipment has been tested and found to comply with the limits for a FCC Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. The equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to the radio communications. Operation in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

International: This is a CISPR 32 Class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.Each station can activate up to two solenoids.

Products with transformer: Utilize a Class 2 transformer tested to UL1585 and satisfies the requirements of a Class 2 Power Source as defined in the NFPA 70 (NEC), Article 725.121(A) (3).





WARNING: Cancer and Reproductive harm – www.P65Warnings.ca.gov. For more information, please visit www.toro.com/CAProp65.

Patent: www.ttcopats.com