


**TORO**®

**NEW!**

**PERFORMANCE SERIES**

**NOZZLES**

**FOR INFINITY® & FLEX800™ SPRINKLERS**



[toro.com/golf](http://toro.com/golf)

# ***THE BEST*** ***JUST GOT BETTER.***

**Toro's new Performance Series Nozzles are the next evolution of precise water delivery.** Starting with industry leading distribution uniformity, adding unparalleled versatility, the end result is the ultimate in golf course irrigation efficiency.

The Performance Series for INFINITY<sup>®</sup> and FLEX800<sup>™</sup> Sprinklers take precision irrigation to an all new level.






**PERFORMANCE SERIES**

# **NOZZLES**

**Inlet**



**Outlet**



**FOR INFINITY® & FLEX800™ SERIES SPRINKLERS**

# ***PERFORMANCE*** ***FOR ALL DESIGNS.***

**Performance Series Nozzles** provide a streamlined approach to simplify the design process and optimize water delivery.





















- **Performance Specification for Common Spacings**
- **One Model Color for Each Main Nozzle**
- **New Profile Performance Data for Consultants**


***Water delivery with *precision.****



# INF-FLX34

## Performance Series Nozzle Chart

<b>Nozzle Set (31 to 34)</b>	<b>Nozzle Set 31</b>		<b>Nozzle Set 32</b>		<b>Nozzle Set 33</b>		<b>Nozzle Set 34</b>	
<b>Color</b>	 (Yellow)		 (Blue)		 (Brown)		 (Orange)	
<b>Part #</b>	102-0725		102-0726		102-0727		102-7002	
<b>Stator #</b>	102-6929 Blue							
<b>Front</b>								
<b>Color</b>	(Orange)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)
<b>Part #</b>	102-2926	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335
<b>Back Nozzle Positions</b>								
<b>Color</b>	(White)	(Red)	(Yellow)	(Orange)	(Yellow)	(Red)	(Yellow)	(Beige)
<b>Part #</b>	102-6940	102-4335	102-6937	102-2926	102-6937	102-2928	102-6937	102-2929
<b>Full Circle Dual Trajectory 34</b>								
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50	54	15.5	58	18.5				
65	55	18.0	60	21.1	65	25.4	70	28.9
80	59	19.9	67	23.6	71	28.5	75	32.4
100	61	22.2	70	26.5	76	32.0	79	36.0




■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.




**PERFORMANCE SERIES**

# **NOZZLES**



















## **Nozzle Angle Installation Key**



# INF-FLX34

## Performance Series Nozzle Chart





















Nozzle Set (35 to 37)	Nozzle Set 35		Nozzle Set 36		Nozzle Set 37	
Color						
	(Green)		(Gray)		(Black)	
Part #	102-0729		102-0730		102-4261	
Stator #	102-1940 Red, Black (Circles)					
Front						
	(Red)	(Red)	(Brown)	(Red)	(Red)	(Lt. Blue)
Part #	102-4335	102-4335	102-6883	102-4335	102-4335	118-6700
Back Nozzle Positions						
Color	(Yellow)	(Beige)	(White)	(Beige)	(White)	(Beige)
Part #	102-6937	102-2929	102-6940	102-6942	102-6940	102-6942
<b>Full Circle Dual Trajectory 34</b>						
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50						
65	75	37.4				
80	82	41.3	80	46.8	85	52.3
100	86	46.0	87	52.1	89	58.5




■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.

# INF-FLX35

## Performance Series Nozzle Chart

Nozzle Set (30 to 33)	Nozzle Set 30		Nozzle Set 31		Nozzle Set 32		Nozzle Set 33	
Color	 (White)		 (Yellow)		 (Blue)		 (Brown)	
Part #	102-2208		102-0725		102-0726		102-0727	
Stator #	102-6929 Blue		102-1939 White					
Front								
Color	(Yellow)	(Beige)	(Green)	(Blue)	(Green)	(Blue)	(Green)	(Blue)
Part #	102-5670	102-6942	102-6531	102-2925	102-6531	102-6947	102-6531	102-6947
Back Nozzle Positions								
Color	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)
Part #	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335
<b>Part Circle Dual Trajectory 35</b>								
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50	43	8.2	52	13.8	57	17.9		
65	45	10.0	55	15.9	60	20.4	65	22.6
80	46	11.5	57	17.6	63	22.7	67	24.9
100	47	13.4	58	19.6	67	25.2	70	27.8
























■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.



# INF-FLX35

## Performance Series Nozzle Chart





















Nozzle Set (34 to 37)	Nozzle Set 34		Nozzle Set 35		Nozzle Set 36		Nozzle Set 37	
<b>Color</b>	 (Orange)		 (Green)		 (Gray)		 (Black)	
<b>Part #</b>	102-7002		102-0729		102-0730		102-4261	
<b>Stator #</b>	102-1939 White		118-7282 Red, Pink					
<b>Front</b>								
<b>Color</b>	(Yellow)	(Purple)	(White)	(Yellow)	(White)	(Yellow)	(White)	(Yellow)
<b>Part #</b>	102-5670	118-6699	102-6940	102-6946	102-6940	102-6946	102-6940	102-6946
<b>Back Nozzle Positions</b>								
<b>Color</b>	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)
<b>Part #</b>	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335
<b>Part Circle Dual Trajectory 35</b>								
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50								
65	70	25.6	75	34.2				
80	71	28.5	78	38	80	39.7	85	42.3
100	72	31.7	83	42.5	84	44.5	86	47.3




■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.

# INF-FLX54

## Performance Series Nozzle Chart


























<b>Nozzle Set (51 to 54)</b>	<b>Nozzle Set 51</b>		<b>Nozzle Set 52</b>		<b>Nozzle Set 53</b>		<b>Nozzle Set 54</b>	
<b>Color</b>	 (Yellow)		 (Blue)		 (Brown)		 (Orange)	
<b>Part #</b>	<b>102-0725</b>		<b>102-0726</b>		<b>102-0727</b>		<b>102-7002</b>	
<b>Stator #</b>	<b>102-1939 White</b>							
<b>Front</b>								
<b>Color</b>	(Orange)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)
<b>Part #</b>	102-2926	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335
<b>Back Nozzle Positions</b>								
<b>Color</b>	(White)	(Red)	(Yellow)	(Orange)	(Yellow)	(Red)	(Yellow)	(Beige)
<b>Part #</b>	102-6940	102-4335	102-6937	102-2926	102-6937	102-2928	102-6937	102-2929
<b>Full Circle Dual Trajectory 54</b>								
<b>Pressure (PSI)</b>	<b>Radius (FT)</b>	<b>Flow (GPM)</b>	<b>Radius (FT)</b>	<b>Flow (GPM)</b>	<b>Radius (FT)</b>	<b>Flow (GPM)</b>	<b>Radius (FT)</b>	<b>Flow (GPM)</b>
50	54	15.9	60	18.9				
65	55	18.1	62	21.6	65	25.8	70	29.4
80	58	20.3	68	24.0	70	29.0	75	32.9
100	62	22.7	72	27.0	75	32.5	77	36.5




■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.

# INF-FLX54

## Performance Series Nozzle Chart





















Nozzle Set (55 to 59)	Nozzle Set 55		Nozzle Set 56		Nozzle Set 57		Nozzle Set 58		Nozzle Set 59	
<b>Color</b>	 (Green)		 (Gray)		 (Black)		 (Red)		 (Beige)	
<b>Part #</b>	102-0729		102-0730		102-4261		102-4260		102-4259	
<b>Stator #</b>	102-1940 Red, Black (Circles)									
<b>Front</b>	 (Brown)	 (Red)	 (Brown)	 (Red)	 (Red)	 (Lt. Blue)	 (White)	 (Red)	 (Red)	 (Red)
<b>Part #</b>	102-6883	102-4335	102-6883	102-4335	102-4335	118-6700	102-6940	102-4335	102-4335	102-6944
<b>Back Nozzle Positions</b>	 (White)	 (Beige)	 (White)	 (Beige)	 (White)	 (Beige)	 (Beige)	 (Gray)	 (White)	 (Red)
<b>Color</b>	(White)	(Beige)	(White)	(Beige)	(White)	(Beige)	(Beige)	(Gray)	(White)	(Red)
<b>Part #</b>	102-6940	102-6942	102-6940	102-6942	102-6940	102-6942	102-6942	102-6945	102-6940	102-4335
<b>Full Circle Dual Trajectory 54</b>										
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50										
65	75	40.8								
80	79	45.6	80	47.3	85	52.9	85	57.9	97	60.7
100	84	50.9	87	53.0	90	59.1	94	65.4	104	67.4




■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.

# INF-FLX55

## Performance Series Nozzle Chart





















Nozzle Set (51 to 54)	Nozzle Set 51		Nozzle Set 52		Nozzle Set 53		Nozzle Set 54	
Color	 (Yellow)		 (Blue)		 (Brown)		 (Orange)	
Part #	102-0725		102-0726		102-0727		102-7002	
Stator #	102-1939 White							
Front								
Color	(Yellow)	(Brown)	(Green)	(Blue)	(Green)	(Blue)	(Yellow)	(Yellow)
Part #	102-5670	102-5671	102-6531	102-6947	102-6531	102-6947	102-5670	102-6884
Back Nozzle Positions								
Color	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)
Part #	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335
<b>Part Circle Dual Trajectory 55</b>								
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50	53	13.9	58	18.1				
65	55	15.3	60	20.7	65	22.9	70	25.9
80	57	17.8	64	23.1	68	25.4	71	29.0
100	59	19.8	68	25.8	72	28.6	73	32.4




■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.

# INF-FLX55

## Performance Series Nozzle Chart





















Nozzle Set (55 to 59)	Nozzle Set 55		Nozzle Set 56		Nozzle Set 57		Nozzle Set 58		Nozzle Set 59	
Color	(Green)		(Gray)		(Black)		(Red)		(Beige)	
Part #	102-0729		102-0730		102-4261		102-4260		102-4259	
Stator #	118-7282 Red, Pink								102-1941 Red, Black (Spokes)	
Front	 (White)	 (Yellow)	 (White)	 (Yellow)	 (White)	 (Yellow)	 (White)	 (Yellow)	 (White)	 (Yellow)
Part #	102-6940	102-6946	102-6940	102-6946	102-6940	102-6946	102-6940	102-6946	102-6940	102-6946
Back Nozzle Positions	 (Red)	 (Red)	 (Red)	 (Red)	 (Red)	 (Red)	 (Red)	 (Red)	 (Red)	 (Red)
Color	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)
Part #	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335
<b>Part Circle Dual Trajectory 55</b>										
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50										
65	75	34.6								
80	79	38.5	80	40.0	83	42.9	85	49.0	89	58.1
100	83	43.0	85	45.1	87	48.1	88	54.8	95	64.6




■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.

# INF-FLX55

## Performance Series Nozzle Chart

















Nozzle Set (55 to 59)	Nozzle Set 55		Nozzle Set 56		Nozzle Set 57		Nozzle Set 58		Nozzle Set 59	
Color	(Green)		(Gray)		(Black)		(Red)		(Beige)	
Part #	102-0729		102-0730		102-4261		102-4260		102-4259	
Stator #	118-7282 Red, Pink								102-1941 Red, Black (Spokes)	
Front										
Color	(White)	(Yellow)	(White)	(Yellow)	(White)	(Yellow)	(White)	(Yellow)	(White)	(Yellow)
Part #	102-6940	102-6946	102-6940	102-6946	102-6940	102-6946	102-6940	102-6946	102-6940	102-6946
Back Nozzle Positions										
Color	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)	(Red)
Part #	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335	102-4335
<b>Part Circle Dual Trajectory 55</b>										
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50										
65	75	34.6								
80	79	38.5	80	40.0	83	42.9	85	49.0	89	58.1
100	83	43.0	85	45.1	87	48.1	88	54.8	95	64.6




■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.

# INF-FLX35-6

## Performance Series Nozzle Chart

















Nozzle Set (30 to 33)	Nozzle Set 30		Nozzle Set 31		Nozzle Set 32		Nozzle Set 33	
Color	 (White)		 (Yellow)		 (Blue)		 (Brown)	
Part #	102-2208		102-0725		102-0726		102-0727	
Stator #	102-6929 Blue			102-1939 White				
Front								
Color	(Blue)	(Gray)	(Black)	(Green)	(Black)	(Dark Red)	(Black)	(Dark Red)
Part #	102-2925	102-2910	102-6941	118-6697	102-6941	118-6698	102-6941	118-6698
Back Nozzle Positions								
Color	(Red)		(Red)		(Red)		(Red)	
Part #	102-4335		102-4335		102-4335		102-4335	
Part Circle Trajectory 35-6								
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50	42	7.6	53	13.9	58	19.4		
65	45	8.3	55	15.9	60	22.3	65	24.3
80	46	9.2	59	17.6	64	24.5	69	26.8
100	48	10.1	61	19.5	68	27.3	73	30.0




■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.

# INF-FLX35-6

## Performance Series Nozzle Chart

<b>Nozzle Set (34 to 37)</b>	<b>Nozzle Set 34</b>		<b>Nozzle Set 35</b>		<b>Nozzle Set 36</b>		<b>Nozzle Set 37</b>	
<b>Color</b>	 (Orange)		 (Green)		 (Gray)		 (Black)	
<b>Part #</b>	102-7002		102-0729		102-0730		102-4261	
<b>Stator #</b>	102-1939 White		118-7282 Red, Pink					
<b>Front</b>	 30°	 -30°		 -30°		 -30°	 30°	 -30°
<b>Color</b>	(Black)	(Dark Red)	(White)	(Purple)	(White)	(Lt. Blue)	(White)	(Lt. Blue)
<b>Part #</b>	102-6941	118-6698	102-6940	118-6699	102-6940	118-6700	102-6940	118-6700
<b>Back Nozzle Positions</b>								
<b>Color</b>	(Red)		(Red)		(Red)		(Red)	
<b>Part #</b>	102-4335		102-4335		102-4335		102-4335	
<b>Part Circle Trajectory 35-6</b>								
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50								
65	70	26.2	75	34.6				
80	73	28.6	79	38.6	80	41.5	85	43.8
100	76	32.0	84	43.1	85	46.5	90	49.3




















■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.



# INF-FLX55-6

## Performance Series Nozzle Chart





















<b>Nozzle Set (51 to 54)</b>	<b>Nozzle Set 51</b>		<b>Nozzle Set 52</b>		<b>Nozzle Set 53</b>		<b>Nozzle Set 54</b>	
<b>Color</b>	 (Yellow)		 (Blue)		 (Brown)		 (Orange)	
<b>Part #</b>	102-0725		102-0726		102-0727		102-7002	
<b>Stator #</b>	102-1939 White							
<b>Front</b>								
<b>Color</b>	(Black)	(Green)	(Black)	(Dark Red)	(Black)	(Dark Red)	(Black)	(Purple)
<b>Part #</b>	102-6941	118-6697	102-6941	118-6698	102-6941	118-6698	102-6941	118-6699
<b>Back Nozzle Positions</b>								
<b>Color</b>	(Red)		(Red)		(Red)		(Red)	
<b>Part #</b>	102-4335		102-4335		102-4335		102-4335	
<b>Part Circle TruJectory 55-6</b>								
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50	53	14.5	58	19.9				
65	55	16.5	60	22.9	65	25.4	70	26.9
80	59	18.2	65	25	70	27.6	73	30.4
100	61	20.3	70	28	74	30.7	76	33.9




■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.

# INF-FLX55-6

## Performance Series Nozzle Chart


Nozzle Set (55 to 59)	Nozzle Set 55		Nozzle Set 56		Nozzle Set 57		Nozzle Set 58		Nozzle Set 59	
Color	 (Green)		 (Gray)		 (Black)		 (Red)		 (Beige)	
Part #	102-0729		102-0730		102-4261		102-4260		102-4259	
Stator #	102-1940 Red, Black (Circles)								102-1941 Red, Black (Spokes)	
Front	 (White)	 (Purple)	 (White)	 (Purple)	 (White)	 (Purple)	 (Black)	 (Lt. Blue)	 (Black)	 (Red)
Part #	102-6940	118-6699	102-6940	118-6699	102-6940	118-6699	102-6941	118-6700	102-6941	102-6944
Back Nozzle Positions	 (Red)		 (Red)		 (Red)		 (Red)		 (Red)	
Color	(Red)		(Red)		(Red)		(Red)		(Red)	
Part #	102-4335		102-4335		102-4335		102-4335		102-4335	
<b>Part Circle TruJectory 55-6</b>										
Pressure (PSI)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)	Radius (FT)	Flow (GPM)
50										
65	75	35.1								
80	80	39.3	80	40.7	85	43.2	88	51.0	95	60.1
100	85	43.9	88	46.1	90	49.8	90	56.3	100	66.3



■ Not recommended at these pressures. Radius shown in feet. Toro® recommends the use of a 1 1/4" swing joint at flows over 25-gpm (95-LPM). Sprinkler radius data collected in Toro's zero wind test facility per ASAE standard S398.1. Actual site conditions must be considered when selecting the appropriate nozzle. All sprinklers are equipped with the selectable pilot valve that allows settings at 50, 65, 80 and 100 psi.

# ***UNMATCHED*** ***PERFORMANCE.***

**Designed to outperform the industry standard,** Toro's new Performance Series Nozzles, loaded into Infinity or Flex rotors, deliver water with precision and efficiency. Call or visit your distributor to learn more.



# ***DISTRIBUTOR*** **PARTNERS.**

## **American Golf Partners (a-z)**

**1.) Century Equipment, Inc.**

(419) 865-7400

**2.) E. H. Griffith, Inc.**

(412) 271-3365

**3.) Grassland Equipment & Irrigation Corp.**

(518) 785-5841

**4.) Ness Turf Equipment**

(808) 486-8300

**5.) Hector Turf**

(954) 429-3200

**6.) Jerry Pate Turf & Irrigation, Inc.**

(850) 479-4653

**7.) Kenney Machinery Corp.**

(317) 872-4793

**8.) L. L. Johnson Distributing Company**

(303) 320-1270

**9.) Midland Implement Company, Inc.**

(406) 248-7771

**10.) Midwest Turf & Irrigation, Inc.**

(402) 895-8900

**11.) MTI Distributing, Inc.**

(763) 592-5600

**12.) Professional Turf Products**

(817) 785-1900

**13.) Reinders, Inc.**

(262) 786-3300

**14.) Simpson Norton Corporation**

(623) 932-5116

**15.) Smith Turf & Irrigation L.L.C.**

(704) 393-8873

**16.) Spartan Distributors, Inc.**

(616) 887-7301

**17.) Storr Tractor Company**

(908) 722-9830

**18.) Turf Equipment & Irrigation**

(801) 566-3256

**19.) Turf Equipment & Supply Company, Inc.**

(410) 799-5575

**20.) Turf Products L.L.C.**

(860) 763-3581

**21.) Turf Star Western**

(800) 585-8001

**22.) Wesco Turf Inc.**

(941) 377-6777

## **Canadian Golf Partners (a-z)**

**23.) Ful-Flo Industries, Ltd.**

(204) 633-4414

**24.) Oakcreek Golf and Turf Inc.**

(403) 279-2907

**25.) Turf Care Products Canada**

(905) 836-0988





***Always solving. Always evolving.***

**#1 in Golf Irrigation & Equipment\***



[www.toro.com](http://www.toro.com)

5825 Jasmine Street  
Riverside, CA 92504-1183  
Phone: 877-345-8676  
Fax: 800-862-8676

©2023 The Toro Company  
All Rights Reserved

P/N: 23-5181-IG-NA

[facebook.com/Toro.Company](https://facebook.com/Toro.Company)  
[twitter.com/torogolf](https://twitter.com/torogolf)  
[youtube.com/toro](https://youtube.com/toro)

We reserve the right to improve our products and make changes in the specifications and designs without notice and without incurring obligation.

Products depicted in this brochure are for demonstration purposes only.

Actual products offered for sale may vary in design and features.

\*Based on market share data from National Golf Foundation Turf Brand Health Survey 2022.

This statement has not been evaluated or endorsed by any regulatory agency.